

Vission Control Manual

Local-Stop Ready, (SP)
Setpt #1

1/25/2007 15:17:48
Runtime: 44:12:00
Oil Heater: Off
Oil Pump: Off

Ambient Temp

Suction
24 psig
25 °F

Discharge
33 psig
121 °F

Motor Amps
0 amps

% Max RPM
0 *VFD Only*

Pressure Ratio
1.2 PR *SOI Only*

Oil Filter
In 80 psig
Out 80 psig
diff 0 psid

Oil Injection
55 psid diff
117 °F

Sump
117 °F

Ammonia (R717)

Cap Inc % CAP
0 %

Cap Dec

Unit Start

Alarm Reset

Stop


Vol Inc % VOL
0 %

Vol Dec

Service Required String

Menu Setup Maintenance Version Help

Important Note



⚠ DANGER

Read and understand operator's manual before using/ servicing this machine.

Failure to follow operating instructions could result in serious injury Possible Electrocution or burn.

Follow lockout/tag out procedures before working inside this equipment.

Before applying power to the VISSION MicroController panel, all wiring to the panel should be per NEC. Specifically check for proper voltage and that the neutral is grounded at the source. An equipment ground should also be run to the panel.

*See Wiring Instructions and Diagrams before proceeding.

Before start-up you need to enter all system values and options, see section on Setpoint Values.

“Before powering the Vission control panel down”, it is a good idea to Backup Control Settings to insure that all previously changed setpoints have been properly saved. See section on saving changes. After backing up the setpoints **DO NOT** power down the Vission panel for at least 1 minute. This will allow adequate time for all setpoints to be properly saved.

Note: The screen shots depicted in this manual represent the screens corresponding to Vission program version # 2.4.41, the current version at time of printing. In our effort to continuously improve the functionality and ease-of-use of the Vission Micro-controller, the look of some screens may differ slightly than the representations shown here.

Equipment Identification Numbers:

Vilter Order Number: _____ Serial Number: _____
Vilter Order Number: _____ Serial Number: _____
Vilter Order Number: _____ Serial Number: _____

Table of Contents

Important Note	3
STANDARD VILTER WARRANTY STATEMENT	6
Operational Flow Chart	8
Operational Flow Chart (cont.)	9
Wiring Instructions	11
Wiring Instructions For Vission Only	12
Wiring Diagram For Vission Only	20
Main Screen	22
Set Up Screen.....	23
Version Screen	25
Maintenance Screen	26
Menu Screen	28
Common Buttons.....	29
Compressor Control	30
Additional Compressor Controls	32
Compressor Alarm and Trip	35
Compressor Setpoints and Alarms.....	37
Miscellaneous Screens (Condenser Control)	41
Compressor Sequencing (Max 5 Compressors)	43
Vilter Only Screen	47
Diagnostics Force Output	48
Instrument Calibration	49
Calibration Procedure of Optical Actuators.....	51
Installation Instructions For Replacement Of Optical Actuator.....	54
Slide Valve Actuator Troubleshooting Guide	55
Slide Wiring Diagram for Models Vission VSM-91 To VSS-601.....	59
Slide Wiring Diagram for Models Vission VSS-751 To VSS-1801	60
Command Shaft Rotation and Travel.....	61
Calibration For Earlier Style Mechanical Gearmotor/Potentiometers	62
Trend Chart	64
Data Select Screen	65
Event List	66
Trouble Shooting Flowchart (Vission Only)	68

Safety Failure Message	70
Supressor Kit Installation	73
Flash Card Installation Instructions	74
Back Light Installation Instructions	76
System Setpoints Alarms and Trips Work Sheet	80
System Control Limit Values Work Sheet.....	81
System Timer Values.....	82
Spare Parts	84
Modifications for Analog Board (Vission/Vantage after July 2003)	85
Danfoss Liquid Injection Valves	87
Who to Contact	88

STANDARD VILTER WARRANTY STATEMENT


Seller warrants the products it manufactures to be free from defects in material and workmanship for a period of eighteen (18) months from the date of shipment from Seller's manufacturing plant or twelve (12) months from date of installation at the initial end users location, whichever occurs first. In addition, Seller provides the following extended warranties: (a) three (3) years from the date of shipment on single screw compressor internal rotating parts, (b) two (2) years from the date of shipment on reciprocating compressors and single screw and reciprocating compressor parts, and (c) two (2) years on all other parts on a single screw compressor unit. Such warranties do not apply to ordinary wear and tear. Seller does not warrant that the product complies with any particular law or regulation not explicitly set forth in the specifications, and Buyer is responsible for ensuring that the product contains all features necessary to safely perform in Buyers and its customers plants and operations. Buyer must notify Seller of any warranty claim within ten (10) days after such claim arises, otherwise Buyer waives all rights to such claim. Products supplied by Seller, which are manufactured by others, are not warranted by Seller, but rather Seller merely passes through the manufacturers warranty to Buyer.

SELLER EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.


Unless otherwise agreed in writing, Buyers sole remedy for breach of warranty is, at Sellers option, the repair of the defect, the correction of the service, or the providing a replacement part FOB Sellers office. Seller will not be responsible for costs of dismantling, lost refrigerant, reassembling, or transporting the product. Further, Seller will not be liable for any other direct, indirect, consequential, incidental, or special damages arising out of a breach of warranty. **THESE WARRANTY REMEDIES ARE EXCLUSIVE AND ALL OTHER WARRANTY REMEDIES ARE EXCLUDED.** Products or parts for which a warranty claim is made are to be returned transportation prepaid to Sellers factory. Any improper use, corrosion, neglect, accident, operation beyond rated capacity, substitution of parts not approved by Seller, or any alteration or repair by others which, in Sellers judgement, adversely affects the Product, shall void all warranties and warranty obligations. Further, Seller shall not be liable under the above warranties should Buyer be in default of its payment obligations to Seller under this Agreement or any credit agreement.

Operational Flow Chart


Requirements to Start Compressor




Critical Compressor Run Logic @ Compressor Start



Compressor Amperage Load Limiting




High Dsch Pressure Load Limit



Operational Flow Chart (cont.)

Suction Press Over-ride Load Limit During Temperature Control



Wiring Instructions



Wiring Instructions For Vission Only

Mandatory Wiring

Step #1


Power Connections Required
(#16 AWG. Nominal)

- 5-1= Main Power to Panel
- 5-2= Heater #1 power
- 5-5= Heater #2 Power



If heater relay circuit is to be powered from the same breaker as the control circuit add a jumper from 5-1 to 5-2.
 If heater circuit is to be powered from a different breaker insure this circuit is on the same phase as the control circuit. ("HOT" wire to 5-5)

Heater Circuit Power to 1 or 2 fuses on bottom of panel. Note: Number of fuses based on number of heaters on compressor.



View Inside Of Vission Panel


Wiring Instructions For Vission Only

Mandatory Wiring

Step #2

Motor Starter Contactor Connection

The contact to the pull in the motor starter contactor is a dry contact, place a "HOT" wire from the starter circuit on 7-1. Place the wire to energize the starter contactor on 7-2.



View Inside Of Vission Panel


Wiring Instructions For Vission Only

Mandatory Wiring

Step #3

Motor Starter Auxiliary Contact

"HOT" to 4-5
Wire to energize to 1-1




Wiring Instructions For Vission Only

Mandatory Wiring

Step #4

Oil Pump Starter Connection

"HOT" to 6-1
Wire to energize on 6-2



View Inside Of Vission Panel

Wiring Instructions For Vission Only


Optional Wiring

Step #5

Auxiliary / Safety Wiring

A determination by the user is to be made if this option will be used. If it is *not* used, insure that a jumper is installed between L 2-1 and 1-2

If this option is used, remove the jumper 2-1 to 1-2 and place the high level cutout (typically, other cutouts or an E-stop could be used) common wire on 2-1 and the normally closed wire to 1-2.



Wiring Instructions For Vission Only


Optional Wiring

Step #6

Remote Start Wiring

A determination by the user is to be made if this option will be used. If it is *not* used, insure that a jumper is installed between L 2-1 and 1-5.

If this option is used, remove the jumper 2-1 to 1-5 and place the dry remote start contact common wire on 2-1 and the normally open wire to 1-5.




Wiring Instructions For Vission Only

Optional Wiring

Step #7

Setpoint #1/#2 Selection Wiring


A determination by the user is to be made if this option will be used. This optional input does not need to be closed for the compressor to run no jumper is required. If this option is to be used, Place the dry contact common wire on L 2-7 and normally open on 1-3





View Inside Of Vission Panel

Note Page

Wiring Diagram For Vision Only



Wiring Diagram For Vision Only



- NOTES:
- 1) WIRING PER NEMA 12.
 - 2) CONTROL WIRING #16 AWG. HEATER WIRING #16 AWG. JIC COLOR CODE UNLESS OTHERWISE NOTED.
 - 3) USE COPPER WIRE WITH AN INSULATION TEMPERATURE RATING OF 60°C MINIMUM.
 - 4) DOTTED WIRING REPRESENTS FIELD WIRING.
 - 5) DOTTED COMPONENTS NOT BY VILTER.
 - 6) * DENOTES CONNECTOR IN VILTER CONTROL PANEL.
 - 7) FOR NEMA 3, DR. 4 & 12 PANELS, ALL OPENINGS TO BE GASKETED.
 - 8) MOTOR STARTER WIRING WILL VARY. REFER TO STARTER MANUFACTURER'S DIAGRAM FOR ACTUAL WIRING.
 - 9) ELECTRICIAN TO ROTATE COMPRESSOR MOTOR CONDUIT BOX (HOLE FACING UP) BEFORE WIRING.
 - 10) ALL CONNECTIONS TO THE PANEL MUST BE MADE WITH FLEXIBLE CONDUIT.
 - 11) USE GREY TUBS EURO-FAST CABLE.
 - 12) "L" TERMINALS ARE LOCATED ON CONNECTORS CON2, CON3 AND CON4 AS NECESSARY.
 - 13) "N" TERMINALS ARE LOCATED ON CONNECTORS CON2, CON3, CON4 AND CON5 AS NECESSARY.
 - 14) TORQUE ON TERMINALS 3-7 INCH POUNDS.
 - 15) SLIDE MOTOR WIRING SHOWN FOR VSM-91 TO VSS-601. FOR ALL OTHER SIZES REVERSE THE BROWN & BLUE WIRES.

ALL AC WIRING TO BE RUN INTO AND ON LEFT SIDE OF PANEL
ALL DC WIRING TO BE RUN INTO AND ON RIGHT SIDE OF PANEL

Main Screen

The Main Screen

This screen has been designed to give the operator an overall view of all operating parameters affecting the compressor package. **This screen should always be displayed when maintenance items and setpoint items are not being performed.** The date on the screen is updated every 1/2 second. Status information such as Alarms and Trips are displayed on the screen.

This Screen contains buttons to navigate to setpoint, setup and maintenance screens.

Status information on the compressor, oil pump, oil heater and run mode.

Start/Stop buttons.


Hour meter.

Motor amperage.

Refrigerant.

Real time compressor and package operating conditions.

Volume and Capacity Slide locations.



Set Up Screen

From the **Main** screen, touch the Setup button. After entering an authorized user name password, the screen pictured below will appear.


Operator Name – This is the same list that appears in the login dialog. Names in this list can be selected for deletion. To change a name or password, you delete the name and enter a new name/password pair. The VILTER operator name cannot be deleted. Emergency passwords provided by a Vilter representative for the **VILTER** name are good only on the date for which they are issued. They are intended to permit navigation to this screen for setup or repair of this list.

Language – The user screens can be seen in English, French, and Spanish, depending on the option selected. Some text will still display in English even when another language is selected.


Pressure Units – Select units of measure for pressure readings. Choices are psi, kg cm² and kPa. This section only, affects pressures displayed on main screen. On all other screens, units are displayed in psi. On the main screen with psi selected, negative gauge pressures will display as inches of mercury vacuum with the unit “Hg. On other screens, negative numbers are scaled as “psi”.

Temperature Units – Select units of measure for temperature. Choices are Fahrenheit or Celsius.

Refrigerant – The choice R717 (Ammonia).



Touch Here



Set Up Screen

- **Anti-Recycle** – The operator can select from the following AntiRecycle options: True, Accumulative, Modified, or Hot Starts. These select the strategy used to prevent excessive start/stop cycles of the compressor. Timers and counters used to enforce anti-recycling are adjusted and monitored in the Compressor Timer Settings screen, reached from the **Menu** screen. Help for the Timer Settings screen explains how the different settings and strategies operate.
- **Compressor Control Via** – Operator can choose the method or mode of compressor control. This determines which measured variable is used in making loading (capacity control) decisions. The choice selected here determines which setpoints are made available for adjustment on the Compressor Control Setpoints screen.
- **Delete Operator** – Operator can choose to delete operator names from the authorized operator listing. A name in the list is selected by touching it. The selected name will be deleted from the list when this button is pushed. If you delete all the names (besides VILTER), be sure you add at least one before leaving this screen.
- **Add Operator** – The button opens a dialog for entry of a new name/password pair. Nothing (leaving the password text box blank) is a legal password. The password is not obscured as it is typed in, so untrusted parties should not be permitted to view the screen during entry. The password is not confirmed with a repeat entry, so verify it visually before pressing okay. Up to 25 name/password pairs can be added. The Operator Name list box will acquire a scroll bar when it fills.
- **Slide Non-Movement** – Alarm enable and disable buttons permit selecting whether an alarm should be generated when failure of slides to move is detected.
- **Setpoint #1 Oil Pump #2 Oil Pump** – For single stage and high stage operation, part time or normal oil pump function are used. The oil pump shuts off after discharge pressure has risen sufficiently to drive oil injection. Oil pump operating mode is independently settable for setpoint groups # 1 and # 2.
- **Modbus Slave Network Address** – When multiple MicroControllers are connected on a Modbus Network, each controller must have a unique address from the other MicroControllers on the network. Duplicate node addresses are not allowed. The node address of each Vission is determined through the **SETUP** menu. The MicroController that will initiate all conversation on the network **MUST** be defined as node 100 (this is defined as the “master” node). All other node numbers should be in the range of 101 through 174.

This must be set when the extra special port (Com4) is used to control or monitor the compressor via Modbus. It also must be set when the multi-compressor sequencing feature is used. Even though Ethernet is used for the comms, this address establishes the compressor’s identity and role in the sequencing logic.
- **Reset After Power Fail** – When Auto is selected, the compressor will attempt to restart on powering up if it was running in ‘Auto’ when powered down and enabling conditions are met. When ‘Manual’ is selected, the compressor powers up into the ‘Stop’ mode and an explicit command to run is required from an operator or comms channel.
- **Min Run Capacity** – When enabled, the Minimum Run Capacity setting on the Addition Compressor Setpoints screen operates as described in the help for that screen. When multiple compressor sequencing is used, selecting Disable here does not interfere with use of the Min Run Capacity setting in the sequencing logic.

Set Up Screen

Log On, Off, or Save Changes

Log on, off, or save changes

User Name

Password

abc

OK

Cancel

Log Off

Save Changes

Backup Settings

Select name and use [abc] to enter password, then [OK] to log on and exit this dialog.

Use [Cancel] or [x] to exit this dialog without logging on.

You will log off automatically after 15 minutes without activity. Use [Log Off] to secure the control immediately.

Changes are saved to permanent memory with [Save Changes] or when you log off. Allow at least 2 minutes before removing power from the control, or data may be lost.

Backup settings and calibrations only after full testing - the previous file will be overwritten. Permanent memory is restored from backup if data is lost.

Press Log on/Save Button and the above screen will appear. When altering setpoints, log on is necessary. Select appropriate user name and enter password to change setpoints. This screen is also used to backup and save setpoints by pressing (Backup Settings).

*After performing a “Back up Setting” operation, **DO NOT** power down the Vission/Vantage panel for atleast 1 minute. This will allow adequate time to insure all setpoints have been properly stored.*

Version Screen

Version

VILTER Since 1967

Vilter Manufacturing
VISION/VANTAGE
Micro-Controller

Program Version : 2.4.41 SS Sep 25 2007 13:53:41


Vission Version : VSS 5.62-073007gc_2pt

8032 Version : 1.4080701 R717 1201

OK

To View if a customized program has been installed in your unit, go to the main screen and press VERSION, a screen will appear with the program version and the make model of the unit.

Maintenance Screen



Touch Here

From the **Main** screen touch the Maintenance button.

“**Service Item Required**” message indicates that the compressor runtime hours has accumulated to a value - or a point- where service Maintenance is required.

>From the main screen, press the “Maintenance” button. A chart will be shown to indicate what service is required - based on the number of hours the compressor has run.

After the all required service work has been accomplished, press the “Service” button located on the Maintenance screen. A “Services Completed” screen will appear. Press on each service that has been completed. A “check” will appear next to each item that has been pressed. When all required services have been completed, and the appropriate box has been checked in the “Services Completed” screen, then the “Service Item Required” message will disappear on the main screen.

Note: All of the service items listed for that interval must be checked before the “Servicing Item Required” message will disappear.

Maintenance Screen

GROUP		INSPECTION OR MAINTENANCE ITEM	SERVICE INTERVAL (HOURS)													
			200	5,000	10,000	20,000	30,000	40,000	50,000	60,000	70,000	80,000	90,000	100,000	110,000	120,000
OIL CIRCUIT		Oil Change (1)		R		R		R		R		R		R		R
		Oil Analysis (2)		S	S	S	S	S	S	S	S	S	S	S	S	S
		Oil Filters (3)	R	R	R	R	R	R	R	R	R	R	R	R	R	R
		Oil Strainer	I	I	I	I	I	I	I	I	I	I	I	I	I	I
PACKAGE		Coalescing Elements					R			R				R		R
		Suction Screen	I	I	I	I	I	I	I	I	I	I	I	I	I	I
		Liquid Line Strainers	I	I	I	I	I	I	I	I	I	I	I	I	I	I
		Coupling Alignment and Integrity	I	I	I	I	I	I	I	I	I	I	I	I	I	I
CONTROL CALIBRATION		Transducers	I	I	I	I	I	I	I	I	I	I	I	I	I	I
		RTD's	I	I	I	I	I	I	I	I	I	I	I	I	I	I
COMPRESSOR		Inspect Compressor		I		I		I		I		I		I		I
		Bearings														I

Key: I Inspect.
R Replace.
S Sample.

Notes: (1) The oil should be changed at these intervals, unless oil analysis results exceed the allowable limits. The frequency of changes will depend on the system cleanliness.
(2) Oil analysis should be done at these intervals as a minimum; the frequency of analysis will depend on system cleanliness.
(3) The oil filter(s) on a minimum must be changed at these intervals or annually if not run continuously. However, the oil filter(s) must be changed if the oil filter differential exceeds 12 psi or oil analysis requires it.

This screen shows the chart of routine maintenance to be performed on the machine at hourly intervals from 200 hours to 120,000 hours.

Services Completed		
<input type="checkbox"/> Oil Change	<input type="checkbox"/> Coalescing Elements	<input type="checkbox"/> Transducer Calibration
<input type="checkbox"/> Oil Analysis	<input type="checkbox"/> Suction Screen	<input type="checkbox"/> RTD Calibration
<input type="checkbox"/> Oil Filters	<input type="checkbox"/> Liquid Line Strainers	<input type="checkbox"/> Inspect Compressor
<input type="checkbox"/> Oil Strainer	<input type="checkbox"/> Coupling Alignment	<input type="checkbox"/> Inspect Bearings

OK
Cancel
Add Note


The Service Button from the Maintenance Screen will bring you to this screen.

When entering service items that were completed, make sure to check all items that are listed to be done at that service interval.


Menu Screen

At the bottom of the **Main** screen touch the Menu button to bring up the screen shown in Figure below.



Use this screen to navigate to the other setpoint screens contained within the program. Each screen has a help button to describe the function of the screen.



Touch Here



Common Buttons




A. Common Buttons

There are several buttons that are common for all menu screens:

- **Return to Menu** – This button always returns you to the **Menu** screen
- **Logon To Edit** – The user is allowed to view data at all screen levels but cannot edit data until a login has occurred. In order to logon, press the arrow next to user name, select user then press the abc button, the key pad screen will appear. Enter your password and hit OK.
- **Set** – To change a value, the operator must first press the SET button and then the text field of the value they want to modify. A number pad will pop up for ease in entry.
- **Help** – This screen will provide more information to the user about the operation of the microprocessor.

Compressor Control



Level 1 Access – Compressor Control Setpoints

From the **Menu** screen, press the Compressor Control setpoints button. The compressor control setpoints screen will be shown.

These screens enable the operator to view and adjust settings that affect compressor control.

From the **Setup** screen, the operator can choose the method or mode of compressor control:

- Compressor Control Via
- Suction Pressure
- Process Temperature
- Discharge Pressure

Once the method is chosen, the appropriate setpoints are then displayed on the Compressor Control Setpoints screen.

The compressor will decide when to increase or decrease capacity by comparing the controlled variable to the setpoints. The maximum on time and minimum off time settings for slide actuator motors can be used to reduce hunting or improve response time. The de-

fault settings of 3 and 20 seconds respectively, provide good operation over a wide range of conditions.

Also on this screen, the following buttons are displayed:

- **Event List** – Provides a chronological event listing.
- **Chart** – Provides a line graph showing process values over a range of time.
- **Auto** – Places the capacity slides into automatic mode. In automatic mode, the capacity slide moves according to control setpoint information.
- **Manual** – Places the capacity slides into manual mode. In manual mode, the capacity slide moves based on input from the operator.

Compressor Control

Setpoints on this screen:

- **Suction Pressure On/Off** – The compressor will automatically cycle ON and OFF at the setpoints entered. Suction Pressure On/Off control is only active if the Compressor Control Via Suction Pressure option is selected on the **Setup** screen. If a compressor shutdown is desired on a suction pressure drop and a manual reset is required, set the OFF value below the Low Suction Pressure Safety Trip value. This will shut down the unit and a reset will be required to restart it.
- **Suction Pressure Capacity Increase** – The capacity of the compressor will increase when suction pressure is at or above the Increase ON setpoint, and the increase “off” timer has cycled. Capacity will continue to increase until the Suction Pressure Capacity Increase OFF setpoint is reached. If closer system control is desired, set the ON and OFF setpoints at the same values. This will essentially eliminate any differential between the ON and OFF setpoints.
- **Suction Pressure Capacity Decrease** – The capacity of the compressor will decrease when suction pressure is at or below the ON setpoint, and the decrease “off” timer has cycled. Capacity will continue to decrease until the Suction Pressure Capacity Decrease OFF setpoint is reached. If closer system control is desired, set the ON and OFF setpoints at the same values. This will essentially eliminate any differential between the ON and OFF setpoints. While this setting is only available for adjustment on the Control Setpoints screen when the Compressor Control Via Suction Pressure option is selected on the **Setup** screen, it has an override effect when control is via process temperature as described below.
- **Capacity Control °F On/Off** – The compressor will automatically cycle ON and OFF at the setpoints entered. Capacity Control °F On/Off is only active if the Compressor Control via Process Temperature option is selected on the **Setup** screen. If compressor shutdown is desired on a process temperature drop and a manual reset is required, set the OFF value below the Low Control Temperature safety trip value. This will shut down the unit and a reset will be required to restart it.
- **Capacity Control °F Increase** – The capacity of the compressor will increase when process temperature is at or above the ON setpoint, and the increase “off” timer has cycled. Capacity will continue to increase until the Capacity Control °F Increase OFF setpoint is reached. If closer system control is desired, set the ON and OFF setpoints at the same values. This will essentially eliminate any differential between the ON and OFF setpoints. Process temperature control of the capacity is active only if the Compressor Control Via Process Temperature option is selected on the **Setup** screen.
- **Process Temperature Control** – Provides for a Suction Pressure Override feature. If the suction pressure should drop below the Suction Pressure Capacity Decrease OFF setpoint, the Suction Pressure Capacity Decrease OFF setpoint will override the Capacity Control °F Increase and prevent the compressor capacity from increasing (loading). If the suction pressure should continue to decrease below the Suction Pressure Capacity Decrease ON setpoint, the compressor capacity will be forced to decrease until the suction pressure is just above the Suction Pressure Capacity Decrease ON setpoint. This will help stabilize the suction pressure, allowing for the process temperature to be gradually pulled down. The Suction Pressure Capacity Decrease ON and OFF setpoints can be viewed or adjusted by temporarily selecting “Processor Control Via Suction Pressure” on the **Setup** screen.
- **Capacity Control °F Decrease** – The capacity of the compressor will decrease when the process temperature is at or below the ON setpoint and the decrease “off” timer has cycled. Capacity will continue to decrease until the Capacity Control °F Decrease OFF setpoint is reached. If closer system control is desired, set the ON and OFF setpoints at the same values. This will essentially eliminate any differential between the ON and OFF

Additional Compressor Controls

Compressor Control Setpoints (Page 2 of 2)					
High Discharge Pressure Unload	Setpoint No. 1	On 200 psig	Off 190 psig	Back to Menu	Back
	Setpoint No. 2	200 psig	190 psig		
Lo Suction Pressure Load Limit	Setpoint No. 1	30.0 psig	35.0 psig	Luguri / Save	Set
	Setpoint No. 2	40.0 psig	45.0 psig		
Motor Amps Load Limit	Setpoint No. 1	5 amps	10 amps	Help	Help
	Setpoint No. 2	5 amps	10 amps		
Oil Separator Heater Temp.		95 °F	105 °F		
Liquid Injection Sol Control Temp		120 °F	105 °F	Current Transformer Ratio	250 CR
Oil Pump Restart		2.8 PR	3.0 PR	Volume Slide Adj. Factor	10 %
Capacity Slide Adj. Range		100 %	100 %		
Minimum Run Capacity		30 %	35 %		
Hnt Gas Bypass @ Capacity		30 %	35 %		
Economizer		80 %	75 %		

Normal Status

High Discharge Pressure Unloading Setpoints 1&2 – Active in Suction Pressure or Process Temperature Capacity Control mode. These setpoints limit the compressor from loading at high discharge pressure conditions. They override the Suction Pressure or Process Temperature Capacity Control setpoints. The capacity of the compressor will decrease when the discharge pressure is at or above the ON set point. When the OFF setpoint is reached, the compressor will stop from unloading any further.

Motor Amp. Load Limit Setpoints 1&2 – This control limit is the motor full load current draw and the maximum current draw. This control

limit will only prevent the compressor from loading and does not shut down the compressor if the maximum current draw setpoint is exceeded. The actual values entered may depend on particular circumstances. The function of the setpoint is as follows:

If the motor is operating at the full load amperage (FLA) setting, the compressor is prevented from loading. If the motor amps exceed the MAX setpoint, the compressor is forced to unload until the current is at 1.0625 times above the FLA setting. If the motor being used has a service factor below 1.0625, use a value for the FLA that is 10% lower than the MAX value.

Compressor Control

- **Oil Separator Heater Temperature** – This control limit determines when the oil separator heater is energized. A decrease in oil separator temperature below the ONsetpoint energizes the oil separator heater. On an increase in oil separator temperature above the OFF setpoint, the oil heater is de-energized.

- **Oil Pump Restart** – To determine the ON and OFF values for the pressure ratios, take the absolute discharge pressure (PSIA), and divide it by the absolute suction pressure (PSIA). If the pressure ratio is below the ON setpoint value, the oil pump will restart and stay on until the pressure ratio increases above the OFF setpoint. This enables a high stage compressor with a part time oil pump to temporarily operate under conditions requiring a full time oil pump.

EXAMPLE: To calculate the OFF value, if the absolute discharge pressure is 200 PSIA and the desired absolute suction pressure of the cut-out point is 67 PSIA, the discharge pressure is divided by the suction pressure. The result is a OFF value of approximately 3.0. This would then be entered for the OFF pressure. Now determine the ON value, take the absolute discharge pressure (200 PSIA) and divide this by the desired absolute suction pressure (71 PSIA). This results in a ON valve of 2.8.

- **Capacity Slide Adjustment Range** – This control limit determines the capacity range the Capacity Slide Adjustment factor will be active. The factor will be active from 0% capacity and will be deactivated when the OFFsetpoint is reached. On a decrease in capacity below the ON set point, the factor will be active.

- **Minimum Run Capacity** – The Minimum Run Capacity is the minimum capacity the compressor will be allowed to run at. When the compressor is started, it will be loaded to the Minimum Run Capacity control setpoint minus 5%. This is done to prevent the capacity control from hunting if the load is not great enough to keep the compressor capacity at the Minimum Run

Capacity setpoint. On a call for unloading, the compressor will unload until it reaches the Minimum Run Capacity control setpoint. It will remain there until the suction pressure reduces and the compressor cycles off on the Suction Pressure On/Off control setpoint.

Volume Slide Adjustment Factor – This value is normally zero (0) and will not require changing. However, if the system operating conditions show the volume ratio is not at the optimum value for the system, this value can be adjusted up or down to permit the most efficient positioning of the volume slide valves. To determine the value to enter, first ensure that the system is in a steady operating state and place the volume side in manual. **NOTE:** The volume position setting and increase the volume side position slowly until the lowest amperage level is achieved. If the amperage level rises instead of falls, decrease the volume slide position until the lowest amperage is achieved. Record the differential from the original position. This will then be adjustment factor to enter for our system. **NOTE:** Negative numbers can be used for this setting. This setpoint is active on a drop in capacity below the Capacity Slide Adjustment Range cut-in (ON) setting. The adjustment is disabled when capacity rises above the Adjustment Range OFF setting. Normally, the “ON-Off” set points should both be set at 100%, so the volume side adjustment factor will be applied over the full range of 0 to 100%

- **Economizer Solenoid** – This control limit determines when the economizer solenoid is energized. When the percentage of compressor capacity reduces below the Economizer Solenoid OFFsetpoint, the solenoid is energized.

- **Current Transformer Ratio** – The value entered must agree with the Current Transformer Ratio on the current transformer being used. The current transformer is mounted in the compressor motor conduit box. The ratio is stated as the ratio of measured current to a nominal full scale current in the secondary of 5 amps; only the first of these is entered. For example, if the ratio reads 250/5, enter 250.

· ***Low Suction Pressure Load Limit*** – Active in Discharge Pressure Capacity Control mode only. These setpoints limit the compressor from loading at low suction pressure conditions. They override the discharge pressure capacity control setpoints. When the OFF setpoint is reached (at or below setpoint), the compressor will not be allowed to load any further. If the suction pressure continues to fall, the capacity of the compressor will decrease when the suction pressure is at or below the ON set point. It will stop decreasing when the suction pressure rises to a point that is just below the ON set point.

Compressor Alarm and Trip

Alarm and Trip Setpoints [Page 1 of 2]			
	Alarm	Trip	Reset
Low Suction Pressure			
Setpoint No. 1	3.1 "Hg	4.1 "Hg	2.0 "Hg
Setpoint No. 2	1.0 "Hg	2.0 "Hg	0.0 psig
High Discharge Pressure			
Setpoint No. 1	210 psig	220 psig	205 psig
Setpoint No. 2	220 psig	230 psig	215 psig
Low Suction Temperature	-45 °F	-50 °F	-40 °F
High Discharge Temperature	205 °F	210 °F	200 °F
Low Oil Separator Start Temp.	75 °F	70 °F	80 °F
Low Oil Separator Run Temp.	105 °F	100 °F	110 °F
Low Oil Injection Temperature	95 °F	90 °F	100 °F
High Oil Injection Temperature	145 °F	150 °F	140 °F
Low Control Temperature	-50 °F	-55 °F	-45 °F
High Control Temperature	100 °F		95 °F

Normal Status

Low Suction Pressure Setpoints 1&2 – This is the low suction pressure safety. This safety is active in both temperature and pressure control modes. An alarm or trip will be active on a drop in suction pressure below the setpoint value.

High Discharge Pressure Setpoints 1&2 This is the high discharge pressure safety. The alarm or trip will be active on a rise in discharge pressure above the setpoint value.

Low Oil Separator Temperature – This is the lowest allowable oil separator temperature. The compressor will not be allowed to run if the Oil Separator Temperature is below the trip setting. After the compressor starts, the alarm or trip will be active if the oil temperature in the separator drops below the setpoint value.

High Discharge Temperature – This is the high discharge temperature safety. The alarm or trip will be active if the discharge temperature should rise above the setpoint value.

Low Oil Separator Start Temperature – This is the starting low oil separator temperature safety. The compressor is prevented from starting or running if the oil in the separator is below the trip value. After a time delay (Oil Separator Temperature Safety Changeover), this safety is deactivated and the Lo Oil Separator Run Temperature is the active setpoint.

Low Oil Separator Run Temperature – This is the running low oil separator temperature safety. After a time delay (Oil Separator Temperature Safety Changeover), the Lo Oil Separator Start Temperature is bypassed and Lo Oil Separator Run Temperature is the active

Compressor Alarm and Trip

setpoint. The alarm or trip will be active if the oil temperature of the separator drops below the setpoint value.

- **Low Oil Injection Temperature** – This is the low oil injection safety. The alarm or trip will be active if oil injection temperature drops below setpoint value after a time delay (Oil Injection Temperature Safety Changeover).
- **High Oil Injection Temperature** – This is the high oil injection temperature safety. The alarm or trip will be active on a rise in oil injection temperature above the setpoint value.
- **Low Control Temperature** – This is the low control temperature safety. This safety is active when process temperature control has been selected in the **Setup** screen. An alarm or trip will be active on a drop in process temperature below the setpoint value.
- **High Control Temperature** – This is the high control temperature safety. This safety is active when the temperature control has been selected in the **Setup** screen. An alarm will be active on an increase in process temperature above the setpoint value.

Compressor Setpoints and Alarms

Compressor Alarm and Trip Setpoints [Page 2 of 2]			
	Alarm	Trip	Reset
Prelube Oil Pressure		6 psig	8 psig
Low Oil Pressure	38 psig	35 psig	40 psig
High Fltr. Diff. Press. -Start	45 psid	50 psid	25 psid
High Fltr. Diff. Press. -Run	12 psid	15 psid	10 psid
High Motor Amps	15 amps	15 amps	1000 amps

Normal Status

- Prelube Oil Pressure** – If the oil pressure does not rise above the reset setting for a time exceeding the Minimum Compressor Prelube Time and the pump runs longer than the Prelube Pump Time Limit, an alarm or trip will occur. These time limits are set on the Compressor Timer Setpoints screen. Prelube oil pressure is defined as the amount that the oil pump drives manifold pressure above the discharge pressure.
- Low Oil Pressure** – This is the running oil pressure safety. An alarm or trip will be active if the oil pressure should drop below the setpoint value. This occurs once the Oil Pressure Bypass timer has expired. The time limit is set on the Compressor Timer Setpoints screen. For the single screw compressor, oil pressure is defined as manifold pressure minus suction pressure.
- High Filter Differential Pressure Start** – This safety setpoint is active when the compressor is in the start cycle. An alarm or trip will be active if the filter inlet pressure exceeds the filter outlet pressure by the setpoint value.
- High Filter Differential Pressure Run** – This safety setpoint is active when the compressor is in the run cycle. An alarm or trip will be active if the filter inlet pressure exceeds the filter outlet pressure by the setpoint value.
- High Motor Amps** – This safety setpoint is active after the Volume Decrease At Start Timer expires. This timer is not user settable, and in standard applications, is 15 seconds. A trip will occur if the motor amperage exceeds the safety setpoint value. The setpoint should be set at 125% of the motor full load amperage.

Compressor Timer Setpoints

Compressor Timer Setpoints

	Current	Value	
Capacity Decrease at Start	0 sec	15 sec	<div style="background-color: #003366; color: white; padding: 5px; text-align: center;">Back to Menu</div> <div style="background-color: #cccccc; padding: 5px; text-align: center; margin-top: 5px;">Logon / Save</div> <div style="background-color: #cccccc; padding: 5px; text-align: center; margin-top: 5px;">Set</div> <div style="background-color: #cccccc; padding: 5px; text-align: center; margin-top: 5px; border: 1px dashed black;">Help</div>
Compressor Starter Aux. Contact Bypass	0 sec	10 sec	
Volume Slide Adjustment Timer	0 sec	15 sec	
Minimum Compressor Prelube Time	0 sec	5 sec	
Oil Pressure Bypass at Compressor Start	0 sec	60 sec	
Prelube Oil Pump Time Limit	0 sec	30 sec	
Filter Diff. Pressure Safety Changeover	0 sec	60 sec	
Low Oil Separator Level Bypass Timer	0 sec		
After Power Failure	0 min		
Oil Separator Temp. Safety Changeover	0 min		
Low Oil Injection Temp. Bypass	0 min		
Number of Hot Starts per Hour	0		
True AntiRecycle Timer	0 min		
Accumulative AntiRecycle Timer	0 min		

Normal Status

To change a timer setting, you must “Logon to Edit” first. Push the “Set” button then push on the timer setpoint value you wish to change. After the setpoint is changed, press the “Refresh” button. This will refresh the “Current” window, which shows the elapsed time of the timers.

- **Capacity Decrease At Start** – At compressor startup, the capacity motor is held at minimum position for this time period. After the timer expires, the slide is free to move in accordance to the system demands.
- **Compressor Starter Auxiliary Contact Bypass** – This timer is used to bypass the motor amperage input at start. After the timer times out, the program determines if the motor starter has pulled in by testing the amperage channel. If the program determines that the starter did not “pull in”, then the compressor will fail on “Motor Starter Fail” message.
- **Volume Slide Adjustment Timer** – This timer determines the intervals the volume slide is adjusted. If the volume slide is between 2½% & 7% away from the desired volume ratio, the motor is pulsed once toward the desired volume. If the volume slide is more than 7% away from the desired value, the volume slide motor is continuously energized until the valve is within 2½% of the desired value. If the actual position is within 2½% of the desired value, no adjustment will be made.

Compressor Timer Setpoints

- **Minimum Compressor Prelube Timer** – This is the length of time the oil pump will run after establishing the Prelube Oil Pressure, to prime oil circuit before starting the compressor.
- **Oil Pressure Bypass At Compressor Start** – This timer bypasses the Low Oil Pressure limits. The timer starts when the compressor starts. After the timer has cycled, the Low Oil Pressure setpoint is active.
- **Prelube Oil Pump Time Limit** – This timer puts a limit on how long the prelube oil pump is allowed to run without establishing the Prelube Oil Pressure.
- **Filter Differential Pressure Safety Changeover** – This timer bypasses the Hi Run Filter Differential Pressure setting during start, to allow the Hi Start Filter Differential Pressure to protect against High Filter Differential during start. After the timer has cycled, the Hi Run Differential Pressure Safety is active.
- **Low Oil Separator Level Bypass Timer** – This timer bypasses the low oil level switch for momentary drops in the oil level. If the switch is still open after the Low Oil Separator Level Bypass Timer has timed out, the compressor will be shut down and an alarm will be displayed. This timer is available if the unit is equipped with a low oil separator float switch. The oil level switch is standard on all liquid injection units and optional on all others.
- **Auto Restart After Power Failure** – This timer forces the microprocessor to wait for the set time period after a power failure before starting the compressor unit. By staggering the time settings, the compressors can be allowed to start automatically, one at a time, after a power failure. This prevents excessive loads on the power system that could be caused by all of the equipment coming online at the same time. The Power-Up Auto Start operator option must be selected on the **Setup** screen for this option to be active.
- **Oil Separator Temperature Safety Changeover** – This timer allows Low Oil Separator Start Temperature Safety setpoint to protect the compressor against cold oil during starting. After the timer has cycled, the Low Oil Separator Run Temperature is then active.
- **Low Oil Injection Temperature Bypass** – This timer bypasses the Low Oil Injection Temperature Safety Setpoint during start-up. After the timer cycles, the Low Oil Injection Temperature Safety is set.
- **Hot Starts / Hr Counter** – This counter counts compressor starts. After every start, a one-hour timer is reset and starts timing. If the timer times out, the hot starts counter is reset. When the counter reaches its preset value, it will not allow another compressor start until the one-hour timer times out and resets the counter. In other words, the hot starts counter will be reset when the time between compressor starts total one hour. This counter allows repetitive compressor starts, but once the counter has reached its set point, it requires a one-hour window between compressor starts in order for the counter to be reset.
- **True Anti-Recycle Timer** – Once the compressor turns off, the timer will keep the compressor off for the setting of True Anti-Recycle Timer. This timer is used to prevent short cycling of the compressor.
- **Accumulative Anti-Recycle Timer** – This timer also forces a specified time between compressor starts. When the compressor starts, the timer resets then starts timing and accumulates running time. Once the compressor shuts down, it will not be allowed to restart for the remainder of the time left on the Accumulative Anti-Recycle Timer. Unlike the True Anti-Recycle Timer, if the compressor has run for a time period that exceeds the setpoint of the Accumulative Anti-Recycle Timer, then when the compressor shuts down, it will be allowed to restart immediately.

Compressor Timer Setpoints

The compressor restart options (Hot Starts or Anti-Recycle Timers) are selected from the **Setup** screen. One additional Anti-Recycle Timer that can be selected from the **Setup** screen is the Modified Anti-Recycle Timer.

- **Modified Anti-Recycle Timer** – Normally, this anti-recycle timer will function as a True Anti-Recycle Timer. However, if the operator presses the stop button, or if a failure occurs, the anti-recycle timer switches functions and acts as an accumulative type anti-recycle timer. It will allow the compressor to restart when the accumulated runtime and the present off time meets or exceeds the setting of this timer.

Miscellaneous Screens (Condenser Control)

The screenshot displays the 'Condenser Control' interface with the following sections:

- Fan Speed Control Mode:** Includes radio buttons for 'Automatic (PID)' (selected) and 'Manual'. The 'Manual' mode shows a 'Speed' of 0 %.
- Fan Control Status:** Shows 'Condensing Pressure' at 214.6 "Hg and 'Fan Speed' at 0 %.
- Fan Control PID Parameters:** Includes 'Target Setpoint' (0.0 psig), 'Proportional Gain' (0.0), 'Reset Time' (0.0 min), and 'Rate Time' (0.0 min).
- Fan Control PID Limits:** Includes 'Fan On' (100.0 psig), 'Fan Off' (100.0 psig), 'Min Run Time' (0 sec), and 'Max Change Rate' (100 %/min).
- Condenser Pump Control:** Includes 'Cooling On Pressure' (0.0 psig) and 'Cooling Off Pressure' (0.0 psig).

Navigation buttons on the right include 'Back to Menu' (blue), 'Logon / Save' (grey), and 'Set' (grey).

This screen is designed for customized functions only, thus maybe placed as a view only screen.

Note: Changing variables on this screen will not have any effect unless you have a customized program for your unit.

To View if a customized program has been installed in your unit, go to the main screen and press VERSION, a screen will appear with the program version and the make model of the unit.

Miscellaneous Screens (Motor Speed)

The screenshot displays the 'Motor Speed Control' interface. It features two main tuning sections: 'Capacity Slide PID Tuning' and 'VFD Motor PID Tuning'. Each section includes fields for Gain, Reset, Rate, and Max Change Rate. To the right of these sections are navigation buttons: 'Back to Menu', 'Logon / Save', 'Set', and 'Help'. Below the tuning sections is a list of parameters with their current values, including VFD Minimum Speed, Suction Pressure Setpoint #1, Suction Pressure Setpoint #2, Proc Var Lower Deadband, Proc Var Upper Deadband, Cap Slide Deadband, and Unloading Rate. On the far right, there is a 'VFD Control' section with 'Disabled' and 'Enabled' buttons.

Parameter	Value
Capacity Slide PID Tuning - Gain	2.0
Capacity Slide PID Tuning - Reset	0.5 min
Capacity Slide PID Tuning - Rate	0.0 min
Capacity Slide PID Tuning - Max Change Rate	100 %/min
VFD Motor PID Tuning - Gain	1.0
VFD Motor PID Tuning - Reset	1.0 min
VFD Motor PID Tuning - Rate	0.0 min
VFD Motor PID Tuning - Max Change Rate	100 %/min
VFD Minimum Speed	100 %
Suction Pressure Setpoint #1	20.0 psig
Suction Pressure Setpoint #2	25.0 psig
Proc Var Lower Deadband	0.5 psid
Proc Var Upper Deadband	0.5 psid
Cap Slide Deadband	4 %
Unloading Rate	20 %/min

This screen is designed for customized functions only, thus maybe placed as a view only screen.

Note: Changing variables on this screen will not have any effect unless you have a customized program for your unit.

To View if a customized program has been installed in your unit, go to the main screen and press VERSION, a screen will appear with the program version and the make model of the unit.

Compressor Sequencing (Max 5 Compressors)

Compressor Sequencing

Pressure Control Setpoints

Start #1	19.00 psig
Start Lag	21.00 psig
Load Rate 2	20.80 psig
Load Rate 1	18.00 psig
Unload Rate 1	15.00 psig
Unload Rate 2	12.20 psig
STOP	10.00 psig

CAP Load Timers

Load Rate 1	20 sec
Load Rate 2	10 sec

CAP Unload Timers

Unload Rate 1	20 sec
Unload Rate 2	10 sec

Machine Start Time

Start Time: 120 sec

Force Priority 1 Compressor on

Suction Pressure:

Equipment	Node	Central	Priority	Step	Min Cap	Max Cap	Stop Time
Cmp1 <input style="width: 40px;" type="text" value="None"/>	100	<input type="button" value="OFF"/>	1	10	10	95	120
Cmp2 <input style="width: 40px;" type="text" value="None"/>	2	<input type="button" value="OFF"/>	2	10	10	95	120
Cmp3 <input style="width: 40px;" type="text" value="None"/>	3	<input type="button" value="OFF"/>	3	10	10	95	120
Cmp4 <input style="width: 40px;" type="text" value="None"/>	4	<input type="button" value="OFF"/>	4	10	10	95	120
Cmp5 <input style="width: 40px;" type="text" value="None"/>	5	<input type="button" value="OFF"/>	5	10	10	95	120

From the Main Menu (press sequencing), this screen will appear.

You must clear the IP Address before entering a new one.

WARNING! Settings on this screen should be used only by Vilter representatives or persons acting under their direction. Improper setting may require service not covered under warranty.

Screen Capture
 Enabled
 Disabled

Target Volume Slide Location : 06

IP Settings

IP Address:

Subnet Mask:

Compressor Name:

Compressor Sequencing (Max 5 Compressors)

		% Capacity	Set Priority	Current Priority
Cmp1	Comp Sequencing Info found on Master Compressor (Node 100)	0	1	1
Cmp2	Comp Sequencing Info found on Master Compressor (Node 100)	0	2	2
Cmp3	Comp Sequencing Info found on Master Compressor (Node 100)	0	3	3
Cmp4	Comp Sequencing Info found on Master Compressor (Node 100)	0	4	4
Cmp5	Comp Sequencing Info found on Master Compressor (Node 100)	0	5	5

System Pressure: 0.0 psig

Buttons: OK, Help

Note: Sequencing and Remote/Start-Stop can NOT function at the same time- Sequencing will over-ride remote start/stop!

This screen allows the operator to setup a sequencing network. Currently, the MicroController is capable of sequencing 5 compressors. In order for a MicroController to participate on the network, it must have a unique address from the other Controllers on the network. Duplicate node addresses are not allowed. The node address of each is done through the **Setup** menu.

The MicroController which will initiate all conversation on the network **MUST** be defined as node 100. This is defined as the “master” node. All other node numbers should be in the range of 101 through 174.

Ethernet Peer To Peer – In addition to having unique node addresses, all compressors on the Ethernet network must have unique IP addresses and unique names. These are entered from the IP Address/Name screen, accessed from the **VILTER ONLY** screen. The Ethernet IP addresses of each of the five compressors listed are required to be:

Equipment:	Ethernet IP Address
Cmp#1:	10.8.0.73
Cmp#2:	10.8.0.74
Cmp#3:	10.8.0.75
Cmp#4:	10.8.0.76
Cmp#5:	10.8.0.77

Note: IP addresses must be set prior to the microcontrollers being connected together.

The Compressor Sequencing screen only needs to be setup on the “Master” node. The elements of this screen are:

- **Equipment** – Allows the operator to select the size of each compressor. This information is used to make sequencing decisions based on the CFM of the compressor. A valid size **MUST** be chosen for a compressor to participate in sequencing. This field also allows the operator to change the name of each of the five compressors listed.

Compressor Sequencing (Max 5 Compressors)

- **Node** – These node address fields tell the sequencing algorithm which the MicroController will be participating in the sequencing network. Input the node addresses of each Controller, participating on the network, in these fields.

NOTE:

The node addresses for each panel are defined and entered under the **Setup** screen at each individual panel.

- **Central Off/On Buttons** – These buttons indicate whether the compressor has been selected to operate under Central Control. If the button reads “On”, the compressor will be included in the Central Control System. If the button reads “Off”, the compressor will not be included in the Central Control system. Pushing once on the button will toggle the button between “Off” and “On”.

- **Priority** – The Priority fields are used to assign the compressor priority for Central Control. The lower the priority number, the greater the priority of the compressor. Priority #1 compressor is the highest priority compressor. Compressors with higher priority numbers will be lag compressors. A compressor with a priority of 1 will be considered the “lead” compressor. The suction pressure of priority #1 compressor is used to control the system pressure.

Step – This field sets the amount of capacity change that will occur when a compressor is loading or unloading.

NOTE:

Because of the method used to position the slide valve, and the method used to determine when the slide valve position is “close enough” to the target value, the step value should never be less than 5%.

- **Min Cap** – The Minimum Capacity is the lowest capacity, in percentages, that this compressor is allowed to reach during operation. If the system needs to remove additional system capacity, it may shut a compressor off.

Max Cap – The Maximum Capacity is the highest capacity, in percentage, that this compressor is allowed to reach during operation. If the system needs to increase capacity after this compressor has reached its maximum, it may turn on another compressor.

Stop Tmr – The Stop Timer (in seconds) is the amount of time the system must hold a compressor at minimum capacity before the compressor can be shut off.

PRESSURE SETPOINTS:

The 7 pressure setpoints are used to control the system pressure. With the exception of the Start #1 and Start Lag setpoints, all other setpoints must be in decreasing pressures from the previous value.

Start #1 – The Start #1 pressure setpoint is the system pressure at which the Priority 1 compressor will be started.

Start Lag – The Start Lag pressure setpoint will only start the lag compressor, and only after the lead compressor has reached the Max Cap value, and the Machine Start Timer has timed out. The Lead compressor is normally priority, unless it is not available to start due to waiting hot starts, safety trips, etc.

Load Rate 2 – If the system pressure exceeds the Load Rate 2 pressure setpoint for the time specified in the Load Rate 2 Timer, Central Control will attempt to increase the capacity of the system.

Load Rate 1 – If the system pressure exceeds the Load Rate 1 pressure setpoint for the time specified in the Load Rate 1 Timer, Central Control will attempt to increase the capacity of the system.

Compressor Sequencing (Max 5 Compressors)

Unload Rate 1 – If the system pressure falls below the Unload Rate 1 pressure setpoint for the time specified in the Unload Rate 1 Timer, Central Control will attempt to decrease the capacity of the system.

Unload Rate 2 – If the system pressure falls below the Unload Rate 2 pressure setpoint for the time specified in the Unload Rate 2 Timer, Central Control will attempt to decrease the capacity of the system.

Stop – If the system pressure falls below the Stop setpoint, Central Control will immediately try to shut down the lowest priority lag compressor. If there is only one compressor running, Central Control will shut down.

CAP Load Timers – These timers are directly related to the setpoint values described above. The timers are the minutes and seconds that the Central Control algorithm will hold before deciding on an action. The CAP Load Rate Timers are related to the appropriate Load 1 and 2 increase setpoints described above.

CAP Unload Timers – The Capacity Unload Rate Timers are similar to the timers described above, however, they work to decrease system capacity. The CAP Unload Rate Timers are related to the appropriate Unload Rate 1 and 2 decrease setpoints described previously.

Machine Start Time – This timer is the time the system will wait until another compressor is started in an attempt to increase capacity.

Force Priority 1 Compressor On Checkbox - When checked this will override other sequencing logic and priority 1 compressor will always run. Pressing the box alternating checks and unchecks it.

Vilter Only Screen

Vilter Manufacturing Corp. ONLY

WARNING! Settings on this screen should be used only by Vilter representatives or persons acting under their direction. Improper setting may require service not covered under warranty.

Calibrate Touch Screen

Raw Data Screen

Modbus Settings

System Date/Time

IP Address / Name

Screen Capture

Enabled


Disabled

Back to Menu


Target Volume Slide Location : 68

WARNING: Settings on these screens should be used only by Vilter representatives or persons acting under their direction. Improper setting may result in loss of vital data and require service NOT covered under warranty.

Diagnostics Force Output



On/Off – This will turn the force outputs option On/Off. The force outputs that can be modified are as follows: Main Motor Starter, Oil Pump, Economizer Solenoid, Remote Alarm/Trip, Liquid Injection Solenoid, Capacity Increase Motor, Capacity Decrease Motor, Volume Increase Motor and Volume Decrease Motor. You can choose the forced output by pressing the down arrow in the control labeled Available Outputs.



Instrument Calibration

Instrument Calibration [Page 1 of 2]			
	mV Reading	Calibrated Value	
Suction Pressure Trans.	2218 mV	127.0 psig	Calibrate
Discharge Pressure Trans.	996.3 mV	27.6 psig	Calibrate
Oil Man. Pressure Trans.	1130 mV	149.4 psig	Calibrate
Oil Filter Inlet Press. Trans.	1549 mV	149.3 psig	Calibrate
U - 10 volt Input #1	0.0 mV	214.6 "Hg	Calibrate
U-10 volt Input #2	0.0 mV	0.0 psig	Calibrate

Back to Menu

Next

The current values reflect the values presently maintained by the system. The user can perform a one-point calibration by entering an offset value into the respective column. This will automatically adjust the current value and zero out the offset value. Giving max and min values for a respective current value can perform a two-point calibration. The program will automatically adjust the calibration line to meet those values.

The following items can be calibrated at this screen: Discharge Pressure Transducer, Suction Pressure Transducer, Manifold Pressure, 0-10v Input, Oil Filter Inlet Pressure Transducer, Discharge Temperature RTD, Suction Temperature RTD, Oil Injection Temperature RTD, Oil Separator RTD, Process Temperature RTD and Motor Amperage.

Instrument Calibration

Instrument Calibration [Page 2 of 2]


	mV Reading	Calibrated Value		Back to Menu
Suction Temperature RTD	5055 mV	80.1 °F	Calibrate	Back
Discharge Temp. RTD	5040 mV	80.2 °F	Calibrate	
Oil Separator Temp. RTD	5029 mV	111.2 °F	Calibrate	
Oil Injection Temp. RTD	5064 mV	110.1 °F	Calibrate	
Process Temperature RTD	5059 mV	80.2 °F	Calibrate	
Spare RTD #1	5074 mV	26.6 °F	Calibrate	
Spare RTD #2	5076 mV	26.7 °F	Calibrate	
Spare RTD #3	5038 mV	23.2 °F	Calibrate	
Motor Amperage	1274 mV	0.3 amps	Calibrate	

Instrument calibration menu displays the Input channels that can be calibrated to represent the actual values at the sampling points.

The current values reflect the values presently maintained by the system. The user can perform a one point calibration by entering an offset value into the respective column. This will automatically adjust the current value and zero out the offset value.

The following items can be calibrated at this screen: three (3) spare RTDs and two (2) 0-10 volt input.

Calibration Procedure of Optical Actuators




* If you are replacing or reinstalling a new optical actuator see: page 63 first.

ACTUATOR MOTOR CONTROL MODULE CALIBRATION PROCEDURE

1. Disable the Slide Non-Movement Alarm by going to the "Setup" menu on the Vission/Vantage and choosing "Alarm Disable" for the Slide Non Movement Option.
2. Open the plastic cover of the capacity motor by removing the four #10 screws. **Caution: there are wires attached to the connector on the plastic cover. Handling the cover too aggressively could break the wires.**
3. Gently lift the cover and tilt it toward the Turck connectors. Raise the cover enough to be able to press the blue calibrate button and be able to see the red LED on the top of assembly.
4. Press "Menu" on the main screen and then press the "Slide Calibration" button, to enter the slide calibration screen. If you are re-installing a new optical actuator re-connect the yellow and gray cables.
5. Press INC and DEC to move the slide valve and check for the correct rotation. See Table 1 for Actuator/command shaft rotation specifications.
6. Note: If the increase and decrease buttons do not correspond to increase or decrease shaft rotation, swap the blue and brown wires of the "yellow power cable". This will reverse the rotation of the actuator/command shaft.

Calibration Procedure of Optical Actuators

7. Quickly press and release the blue push button on the actuator one time. This places the actuator in calibration mode. The red LED will begin flashing rapidly.
8. Note: When the actuator is in calibration mode, it outputs 0V when the actuator is running and 5V when it is still. Thus, as stated earlier, the actuator voltage will fluctuate during calibration. After the actuator has been calibrated, 0V output will correspond to the minimum position and 5V to the maximum position.
9. Note: The “Slide calibration” screen on the Vission/Vantage has a “Current” window, which displays twice the actuator output voltage. This value, (the % volume and the % capacity) displayed in the “Current Vol” and Current Cap” Windows are meaningless until calibration has been completed.
10. Use the DEC button on the Vission/Vantage panel to drive the slide valve to its minimum “mechanical stop” position. **Do not continue to run the actuator in this direction after the slide valve has reached the stop. Doing so may cause damage to the actuator or the slide valve.**



Do not touch wires, may cause an electrical shock!

Press down on the photochopper shaft to disengage the brake, releasing tension from the motor mount. Use the INC button to pulse the actuator to where the slide is just off of the mechanical stop and there is no tension on the motor shaft.

11. Quickly press and release the blue button on the actuator again. The red LED will now flash at a slower rate, indication that the minimum slide valve position (zero position) has been set.
12. Use the INC button on the Vission/Vantage panel to drive the slide to its maximum “mechanical stop” position. **Do not continue to run the actuator in this direction after the slide valve has reached the stop. Doing so may cause damage to the actuator or the slide valve.** Press down on the photochopper shaft to disengage the brake, releasing tension from the motor mount. Use the DEC button to pulse the actuator to where the slide is just off of its mechanical stop and there is no tension on the motor shaft.
13. Quickly press and release the blue button on the actuator one more time. The red LED will stop flashing. The actuator is now calibrated and knows the minimum and maximum positions of the slide valve it controls. Now the capacity or volume channel of the Vission/Vantage can be calibrated.
14. Use the Dec button to move the actuator towards its minimum position while watching the millivolt readout on the Vission/Vantage screen. Discontinue pressing the DEC button when the millivolt reading the “Current” window above the “Set Min” button is approximately 500 millivolts.

Calibration Procedure of Optical Actuators

15. Now use the DEC and INC buttons to position the slide valve until a value close to 300 millivolts is on the screen. Then, press the “Set Min” button in the capacity or volume slide valve window to tell the controller that this is the minimum millivolt position. Note: The value in the “Current Cap” or “Current Vol” window has no meaning right now.
16. Use the INC button to rotate the actuator towards its maximum position while watching the millivolt readout on the controller screen. Discontinue pressing the INC button when the millivolt reading in the “Current” window is approximately 9200 millivolts (7900 millivolts for the 2783J qualified analog boards applies to only VISSION). You are nearing the mechanical stop position.
17. Pulse the INC button to carefully move the slide valve until the millivolt readout “saturates”, or stops increasing. This is around 9500 millivolts (**8400 millivolts for 2783 qualified analog boards applies to only VISSION**). Record millivolt maximum reading.
18. Pulse the DEC button until the millivolts just start to decrease. (This is the point where the channel drops out of saturation). Adjust millivolt value to 300 millivolts below recorded maximum millivolts in step #17.
19. Press the “Set Max” button.
20. Press the “Main” button to complete calibration and exit the “Slide Calibration” screen. The controller will automatically energize the actuator and drive it back to its minimum position (below 5%) for pre-start-up.
21. Note: Now the “Current Cap” or the “Current Vol” value will be displayed in the window on the “Main” screen and the “Slide Calibration” screen.
22. Gently lower the plastic cover over the top of the actuator to where it contacts the base and o-ring seal. After making sure the cover is seated properly, gently tighten the four #10 screws. **Caution: The plastic cover will crack if the screws are over tightened.**
23. Enable the “Slide Non-Movement Alarm” by going to the “Setup” menu and choosing “Alarm Enable” for the “Slide Non-Movement Option”.
24. This completes the calibration for this channel either capacity or volume. Repeat the same procedure to the other channel.

Installation Instructions For Replacement Of Optical Actuator

CAUTION: WHEN INSTALLING THE OPTICAL SLIDE MOTOR, LOOSEN LOCKING COLLAR BEFORE SLIDING THE COLLAR DOWN THE SHAFT. DO NOT USE A SCREWDRIVER TO PRY LOCKING COLLAR INTO POSITION.

OVERVIEW

Calibration of an optical slide valve actuator is a two step process that must be done for each actuator installed on the compressor. The steps are as follows.

1. The actuator motor control module, located inside the actuator housing, is calibrated so that it knows the minimum and maximum rotational positions of the slide valve it controls. The calibrated actuator will output 0 VDC at the minimum position and 5 VDC at maximum position.
2. After the actuator motor control module has been calibrated for 0-5 Volts, the controlling channel corresponding to the actuator motor (either the capacity or volume) has to be calibrated. This instructs the Vission/Vantage control panel to learn the rotational 0% position & rotation 100% position of the slide valve travel.

Please Note:

Because there is an optical sensor on this motor, DO NOT attempt to calibration in direct sunlight.

3. Before applying power to the Vission/Vantage disconnect the gray and yellow cable.
4. Power the Vission/Vantage back on.
5. Refer to **Calibration Procedure of Optical Actuators** (page 60-62).

Slide Valve Actuator Troubleshooting Guide

Slide Valve Actuator Theory of Operation

The slide valve actuator is a gear-motor with a position sensor. The motor is powered in the forward and reverse directions from the main computer in the control panel. The position sensor tells the main computer the position of the slide valve. The main computer uses the position and process information to decide where to move the slide valve next.

The position sensor works by optically counting motor turns. On the shaft of the motor is a small aluminum “photochopper”. It has a 180 degree fence that passes through the slots of two slotted optocouplers. The optocouplers have an infrared light emitting diode (LED) on one side of the slot and a phototransistor on the other. The phototransistor behaves as a light controlled switch. When the photochopper fence is blocking the slot, light from the LED is prevented from reaching the phototransistor and the switch is open. When photochopper fence is not blocking the slot, the switch is closed.

As the motor turns, the photochopper fence alternately blocks and opens the optocoupler slots, generating a sequence that the position sensor microcontroller can use to determine motor position by counting. Because the motor is connected to the slide valve by gears, knowing the motor position means knowing the slide valve position.

During calibration, the position sensor records the high and low count of motor turns. The operator tells the position sensor when the actuator is at the high or low position with the push button. Refer to the calibration instructions for the detailed calibration procedure.

The position sensor can get “lost” if the motor is moved while the position sensor is not powered. To prevent this, the motor can only be moved electrically while the position sensor is powered. When the position sensor loses power, power is cut to the motor. A capacitor stores enough energy to keep the position sensor circuitry alive long enough for the motor to come to a complete stop and then save the motor position to non-volatile EEPROM memory. When power is restored, the saved motor position is read from EEPROM memory and the actuators resumes normal function

This scheme is not foolproof. If the motor is moved

manually while the power is off or the motor brake has failed, allowing the motor to free wheel for too long after the position sensor loses power, the actuator will become lost.

A brake failure can sometimes be detected by the position sensor. If the motor never stops turning after a power loss, the position sensor detects this, knows it will be lost, and goes immediately into calibrate mode when power is restored.

Slide Valve Actuator Troubleshooting Guide

The actuator cannot be calibrated

Dirt or debris is blocking one or both optocoupler slots

Clean the optocoupler slots with a Q-Tip and rubbing alcohol.

The photochopper fence extends less than about half way into the optocoupler slots

Adjust the photochopper so that the fence extends further into the optocoupler slots. Make sure the motor brake operates freely and the photochopper will not contact the optocouplers when the shaft is pressed down.

The white calibrate wire in the grey Turck cable is grounded

Tape the end of the white wire in the panel and make sure that it cannot touch metal

Dirt and/or condensation on the position sensor boards are causing it to malfunction

Clean the boards with an electronics cleaner or compressed air.

The calibrate button is stuck down

Try to free the stuck button.

The position sensor has failed

Replace the actuator.

Push button is being held down for more than $\frac{3}{4}$ second when going through the calibration procedure

Depress the button quickly and then let go. Each $\frac{3}{4}$ second the button is held down counts as another press.

The actuator goes into calibration mode spontaneously

The white calibrate wire in the grey Turck cable is grounding intermittently

Tape the end of the white wire in the panel and make sure that it cannot touch metal.

A very strong source of electromagnetic interference (EMI), such as a contactor, is in the vicinity of the actuator or grey cable

Increase the distance between the EMI source and the actuator.

Install additional metal shielding material between the EMI source and the actuator or cable.

There is an intermittent failure of the position sensor

Replace the actuator.

The actuator goes into calibration mode every time power is restored after a power loss

The motor brake is not working properly (see theory section above.)

Get the motor brake to where it operates freely and recalibrate.

Replace the actuator

Slide Valve Actuator Troubleshooting Guide

The actuator does not transmit the correct position after a power loss

- The motor was manually moved while the position sensor was not powered. ————— Recalibrate.
- The motor brake is not working properly ————— Get the motor brake to where it operates freely and then recalibrate.
- The position sensor's EEPROM memory has failed ————— Replace the actuator.

There is a rapid clicking noise when the motor is operating

- The photochopper is misaligned with the slotted optocouplers ————— Try to realign or replace the actuator.
- The photochopper is positioned too low on the motor shaft. ————— Adjust the photochopper so that the fence extends further into the optocoupler slots.
- A motor bearing has failed ————— Replace the actuator.

The motor operates in one direction only

- There is a loose connection in the screw terminal blocks ————— Tighten.
- There is a loose or dirty connection in the yellow Turck cable ————— Clean and tighten.
- The position sensor has failed ————— Replace the actuator.
- There is a broken motor lead or winding ————— Replace the actuator.

The motor will not move in either direction

- The thermal switch has tripped because the motor is overheated ————— The motor will resume operation when it cools. This could be caused by a malfunctioning control panel. Consult the factory.
- Any of the reasons listed in "The motor operates in one direction only" ————— See above.
- The command shaft is jammed ————— Free the command shaft.
- Broken gears in the gearmotor ————— Replace the actuator.

The motor runs intermittently, several minutes on, several minutes off


- Motor is overheating and the thermal switch is tripping ————— This could be caused by a malfunctioning control panel. Consult the factory.

Slide Valve Actuator Troubleshooting Guide


<i>The motor runs sporadically</i>	—	Bad thermal switch	—	Replace the actuator.
	—	Any of the reasons listed in “The motor will not move in either direction”	—	See above.
<i>The motor runs but output shaft will not turn</i>	—	Stripped gears inside the gear motor or the armature has come un-pressed from the armature shaft	—	Replace the actuator.

Slide Wiring Diagram for Models *Vission* VSM-91 To VSS-601

VOLUME SLIDE WIRING




CAPACITY SLIDE WIRING




Slide Wiring Diagram for Models *Vission* VSS-751 To VSS-1801

VOLUME SLIDE WIRING



CAPACITY SLIDE WIRING



Command Shaft Rotation and Travel

COMP. MODEL	COMMAND SHAFT ROTATION				NO. OF TURNS / ROTATION CAPACITY TURNS/ANGLE/TRAVEL	ANGLE / SLIDE TRAVEL VOLUME TURNS/ANGLE/TRAVEL
	CAPACITY		VOLUME			
	INC	DEC	INC	DEC		
VSR 111	CW	CCW	CW	CCW	0.91 / 328 / 3.568"	0.52 / 187 / 2.045"
VSR 151	CW	CCW	CW	CCW	0.91 / 328 / 3.568"	0.52 / 187 / 2.045"
VSR 221	CW	CCW	CW	CCW	0.91 / 328 / 3.568"	0.52 / 187 / 2.045"
VSR 301	CW	CCW	CW	CCW	0.91 / 328 / 3.568"	0.52 / 187 / 2.045"
VSS 451	CW	CCW	CW	CCW	0.91 / 328 / 3.568"	0.52 / 187 / 2.045"
VSS 601	CW	CCW	CW	CCW	0.91 / 328 / 3.568"	0.52 / 187 / 2.045"
VSS 751	CCW	CW	CCW	CW	1.09 / 392 / 4.283"	0.63 / 227 / 2.473"
VSS 901	CCW	CW	CCW	CW	1.09 / 392 / 4.283"	0.63 / 227 / 2.473"
VSS 1051	CCW	CW	CCW	CW	1.22 / 439 / 4.777"	0.74 / 266 / 2.889"
VSS 1201	CCW	CW	CCW	CW	1.22 / 439 / 4.777"	0.74 / 266 / 2.889"
VSS 1501	CCW	CW	CCW	CW	1.36 / 490 / 5.325"	0.82 / 295 / 3.200"
VSS 1801	CCW	CW	CCW	CW	1.36 / 490 / 5.325"	0.82 / 295 / 3.200"
VSM 71	CW	CCW	CW	CCW	0.80 / 288 / 3.141"	0.45 / 162 / 1.767"
VSM 91	CW	CCW	CW	CCW	0.80 / 288 / 3.141"	0.45 / 162 / 1.767"
VSM 101	CW	CCW	CW	CCW	0.80 / 288 / 3.141"	0.45 / 162 / 1.767"
VSM 151	CW	CCW	CW	CCW	0.80 / 288 / 3.141"	0.45 / 162 / 1.767"
VSM 181	CW	CCW	CW	CCW	0.80 / 288 / 3.141"	0.45 / 162 / 1.767"
VSM 201	CW	CCW	CW	CCW	0.80 / 288 / 3.141"	0.45 / 162 / 1.767"
VSM 301	CW	CCW	CW	CCW	0.80 / 288 / 3.141"	0.45 / 162 / 1.767"
VSM 361	CW	CCW	CW	CCW	0.80 / 288 / 3.141"	0.45 / 162 / 1.767"
VSM 401	CW	CCW	CW	CCW	0.80 / 288 / 3.141"	0.45 / 162 / 1.767"
VSM 501	CCW	CW	CCW	CW	0.91 / 328 / 3.568"	0.52 / 187 / 2.045"
VSM 601	CCW	CW	CCW	CW	0.91 / 328 / 3.568"	0.52 / 187 / 2.045"
VSM 701	CCW	CW	CCW	CW	0.91 / 328 / 3.568"	0.52 / 187 / 2.045"

Note: These refer to the old style gear motors and DO NOT apply to the optical motors.

Table 1

NOTES:

- a) The large gear on the command shaft has 50 teeth. The teeth are counted when moving the command shaft from the minimum stop position to the maximum stop position.
- b) The manual operating shaft on the gear motor should be turned the **opposite** direction of the desired command shaft rotation.
- c) The capacity and volume control motors are equipped with a brake, if it is necessary to operate the control motors manually, the brake must be disengaged. The brake can be disengaged by pushing on the motor shaft on the cone end. The shaft should be **centered** in its travel. Do not use excessive force manually operating the motor or damage may result.

Calibration For Earlier Style Mechanical Gearmotor/Potentiometers

Capacity Slide Valve Potentiometer Calibration – Move the capacity slides to their minimum position. This can be accomplished by either electrically actuating the slide valve motor through the Force Outputs On or by manually actuating the slide valve motor. To manually actuate the motor, release the brake and turn the hex nut on the gear motor in the proper direction to move the capacity slides to their minimum position (see Table 1).

IMPORTANT

After the slide valves have contacted the internal stop, release the tension in the mechanism by actuating the brake and then manually turn the command shaft back one tooth on the command shaft gear. Failure to do so may result in premature failure of the gear motor.

Remove one of the ¼” socket head cap screws from the potentiometer bracket, loosen the other and turn the potentiometer shaft until a millivolt reading of between 900 and 1100 is displayed in the Current window above the Set Min button. Mesh the potentiometer gear with the command shaft gear and replace the ¼” socket head cap screw. The millivolt reading must remain between 900 and 1100 millivolts. Without changing the gear mesh, remove one ¼” screw, and apply Loctite #242 to the threads. Reinstall the screw finger tight, then repeat the procedure on the remaining screw (do not change the orientation of the lockwashers on the screws). The gear lash must be adjusted so there is no side load on the potentiometer shaft. Tighten and torque the ¼” socket head cap screw to 16 ft/lbs. Recheck the millivolt reading. It must be between 900 and 1100 millivolts. If not, the gear mesh will have to be readjusted.

At this point, press the Set Min button in the Capacity Slide Valve Potentiometer window. Realize that the Current Cap window

will show a value, but it has no meaning at this point. Now turn the command shaft to the fully loaded position. With the slide valve against the mechanical stop, release the tension in the mechanism by actuating the brake and manually turn the command shaft back one tooth on the command shaft gear. This is the maximum millivolt position. Now press the Set Max button. Calibration of the slide is completed AFTER pressing the Main button, to exit the Slide Calibration Screen. Now if you re-enter the Slide Calibration Screen, the correct value will be displayed in the Current Cap window and on the Main screen.

Volume Slide Potentiometer Calibration – Move the volume slides to their minimum position. This can be accomplished by either electrically actuating the slide valve motor through the Slide Calibration Screen INC and DEC buttons, or by manually actuating the slide valve motor. To manually actuate the motor, release the brake and turn the hex nut on the gear motor in the proper direction to move the volume slides to their minimum position (see Table 1).

IMPORTANT

After the slide valves have contacted the internal stop, release the tension in the mechanism by actuating the brake and then manually turn the command shaft back one tooth on the command shaft gear. Failure to do so may result in premature failure of the gear motor.

Remove one of the ¼” socket head cap screws from the potentiometer bracket and loosen the other. Turn the potentiometer shaft until a millivolt reading of between 900 and 1100 is displayed. Mesh the potentiometer gear with the command shaft gear and replace the ¼” socket head cap screw. The millivolt reading must remain between 900

Calibration For Earlier Style Mechanical Gearmotor/Potentiometers


and 1100 millivolts. Without changing the gear mesh, remove one ¼” screw, and apply Loctite #242 to the threads. Reinstall the screw finger tight, then repeat the procedure on the remaining screw (do not change the orientation of the lockwashers on the screws). The gear lash must be adjusted so there is no side load on the potentiometer shaft. Tighten and torque the ¼” socket head cap screw to 16 ft/lbs. Recheck the millivolt reading. It must be between 900 and 1100 millivolts. If not, the gear mesh will have to be readjusted.

At this point, press the Set Min button in the Volume Slide Valve Potentiometer window. Realize that the Current Vol window will show a value, but it has no meaning at this point. Now turn the command shaft to the fully loaded position. With the slide valve against the mechanical stop, release the tensions in the mechanism by actuating the brake and manually turn the command shaft back one tooth on the command shaft gear. This is the maximum millivolt position. Now press the Set Max button. Calibration of the slide is completed AFTER pressing the Main button, to exit the Slide Calibration Screen. Now if you re-enter the Slide Calibration Screen, the correct value will be displayed in the Current Vol window and on the Main screen.

Upgrading from Old Style Gear Motors to Optical Actuators.

Refer to the installation instructions that are supplied with the new Optical Actuators.
(VPN 25972A)

Trend Chart



The trend analysis screen shows recorded data for a logging range of either 60 minutes or 120 hours. Additionally, selections can be made to display segments of the logged data.

To view which selections are being shown hit the data select button.

Note: When the panel is powered down, and powered back up, the "Trend Screen" will default to 120 hours even if you have chosen 60 minutes. Trend data is not retained.

Data Select Screen


Data Selection

<input checked="" type="checkbox"/> Suction Pressure Trans.	<input type="checkbox"/> Suction Temperature RTD	Back to Menu
<input checked="" type="checkbox"/> Discharge Pressure Trans.	<input type="checkbox"/> Discharge Temp. RTD	
<input type="checkbox"/> Oil Filter Inlet Press. Trans.	<input type="checkbox"/> Oil Injection Temp. RTD	<input type="button" value="Set"/>
<input type="checkbox"/> Oil Man. Pressure Trans.	<input type="checkbox"/> Oil Separator Temp. RTD	
<input type="checkbox"/> 0-10 Volt Input #2	<input type="checkbox"/> Process Temperature RTD	
<input type="checkbox"/> 0 - 10 Volt Input #1	<input type="checkbox"/> Spare RTD #1	
<input type="checkbox"/> Run Oil Diff Press	<input type="checkbox"/> Spare RTD #2	
<input type="checkbox"/> Prelube Oil Diff Press	<input type="checkbox"/> Spare RTD #3	
<input type="checkbox"/> Filter Diff Press	<input checked="" type="checkbox"/> % Capacity	
<input type="checkbox"/> Pressure Ratio	<input type="checkbox"/> % Volume	
<input checked="" type="checkbox"/> Mntnr Amperage	<input type="checkbox"/> % Volume Target	
	<input type="checkbox"/> Wld	

Max of 4 items plotted at once. You must uncheck something before you can select more items.

The user has the ability to select which value they would like to see displayed on the graph. Only four selections can be chosen at once to view, even though all data is being accumulated.

Event List



Touch Here

From the **Menu** screen, touch the Event List button. The screen on the next page will appear.

Event List

Event Listing

Event List Maintenance Log Notes

2007/10/02 09:02:04 Suction Pressure SP#1 Fail
2007/10/02 09:02:04 Suction Pressure SP#1 Alarm
2007/10/02 08:45:26 Power Up
2007/10/02 08:41:43 Power Up
2007/09/27 15:47:34 Power Up
2007/09/25 13:39:32 Lo Run Oil Pressure Fail
2007/09/25 13:39:31 Lo Run Oil Pressure Alarm
2007/09/25 13:38:30 Compressor Start
2007/09/25 13:31:41 Start Filter Diff Proc Fail
2007/09/25 13:31:05 Oil Separator Start Temp Fail
2007/09/25 13:31:05 Manifold Pressure Fail
2007/09/25 13:31:05 Manifold Pressure Alarm
2007/09/25 13:30:49 Power Up
2007/09/25 09:45:44 Percent Volume Fail
2007/09/25 09:45:44 Percent Volume Alarm
2007/09/25 09:45:44 Percent Capacity Fail
2007/09/25 09:45:44 Percent Capacity Alarm
2007/09/25 09:45:44 Oil Separator Start Temp Fail

Back to Menu View Note Help

The Event List will give a chronological record of the last 40 events recorded by the controller. These events can be filtered by selecting the Filter box on the upper left of the screen.

Trouble Shooting Flowchart (Vission Only)

MicroController does not boot up, no lights on any boards.

Check to make sure 120VAC is run to "L1" on the Relay board. This is the board on the inside left back of the panel. "L1" is the fifth connector down from the top and the top terminal. The neutral should be brought to any "N" on the relay board.

Check F1 fuse on relay board.

Check F1 fuse on the power supply, located on the front of the door. If all of the above is okay, the power supply may be bad. Check DC voltages on the single board computer interface board, which is the big green board above the power supply. Along the right edge of this board, just above the power supply connector J14, are test points. If proper voltages are not located at these test points, the power supply may be faulty.

MicroController appears to be booted, lights seen on boards and E-stop switch, but no touch screen is evident.

Check cable connections located on the LCD Inverter board. This board is located inside the door on the LCD touch screen back plane above the single board computer. The connector with the pink and white wires, located on the left center of the board is the power supply to the board. The connector on the top right of the board with the black wires has the data wires. If these are inserted correctly, the problem could be bad solder joint on the LCD Inverter board or a component failure.

Check Analog board jumpers J41 & J46. They should be on pins 1 & 2 (center and right pins).

Check the upper DIP switch on the analog board. This identifies the node address of the Analog board. Only switch #1 should be on, the rest off.

MicroController boots up but all data temperatures and pressures are zeroed and do not update.

The MicroController has (2) boards running separate programs. The Analog board located inside the panel on the back right calculates pressures, temperatures, amps and monitors inputs. The single board computer requests this data for action and display. The single board computer will instruct the Analog board to activate outputs or relays as needed. Communication between the boards is RS-485 running at 115200 baud. The cable is basically phone cable with phone jack style connectors. The connector to the single board computer is on the touch screen back panel and is labeled RS-485 Com2 to Analog Bd. The connector on the Analog board is located on the bottom of the board. There are 2 connectors on the analog board, either one can be used.

If this cable is open or disconnected, there will be no communications between the boards. The top two green lights on the Analog board (D10 & D11), located on the bottom left of the board, will be off. The pressures and temperatures will not update. Ensure the cable is plugged in correctly. Try rebooting again. If the problem persists, try moving the cable on the Analog board to the other connector. If not successful, try a different cable on the Analog board to the other connector on the board. If not successful, try a different cable. Any phone style cord should work. If neither of these help, contact the Vilter Home Office.

Trouble Shooting Flowchart (Vission Only)

A bank of pressure or temperature channels no longer function.

There are four fuses on the Analog board that limit the current on the 24VDC to the Analog channels. The fuses are 500 milliamp, located near the power supply connectors and brown in color. LEDs next to the fuses give a visual indication of the status of the fuse, however, it is best to pull the fuse and check them with an ohmmeter. If any are blown, find the shorted device that is responsible for the blown fuse and replace.

F1 protects the +24VDC supply to the pressure transducers and relays.

F2 protects the -12VDC supply which is subregulated to 5VDC required for multiplexers, analog to digital converters and temperature channels.

F3 protects the +12VDC supply, which is subregulated to +5VDC, required for multiplexers, analog to digital converters, and temperature channel.

F4 protects the main +5VDC supply required for most of the components on the analog board.

If F1 blows, the pressure transducers will produce erroneous readings and the relays on the relay board will drop out (de-energize). If F2, F3 or F4 blows, all analog readings will be affected.

A pressure channel reads a negative number over -140

This indicates the transducer wiring or transducer is either open or shorted. Check wiring to print. Check fuses F1, F2, F3 and F4 on analog board.

A temperature channel reads a large negative value over -400°

This indicates the RTD wiring or RTD is open. Check wiring to print. Check fuses F1, F2, F3 & F4 on analog board.

Screen Cursor will not retain calibration.

Calibrate the screen cursor, TWICE, per the instructions provided in the manual.

Go to "IP Address" screen and clear IP Address. Re-enter the same IP address

Go to Change Date/Time and clear both. Re-enter appropriate date and time.

Save changes and backup settings.

Power off the panel.

Power on the panel.

Verify the screen cursor follows the fingertip correctly.

Safety Failure Message

Suction Pressure SP#1 Fail -	This message will appear when the suction pressure falls below the safety setting of the Lo Suction Pressure Trip Setpoint No.1. In addition, this message will appear when the suction pressure reading rises above 300 PSI, indicating an open transducer or bad analog channel.
Suction Pressure SP#2 Fail -	This message will appear when the suction pressure falls below the safety setting of the Lo Suction Pressure Trip Setpoint No.2. In addition, this message will appear when the suction pressure reading rises above 300 PSI, indicating an open transducer.
Discharge Pressure SP#1 Fail –	This message will appear when the discharge pressure exceeds the safety setting of the Hi Dsch Press Trip Setpoint No. 1 . In addition, this message will appear when the discharge pressure reading falls below 30” Hg, indicating a shorted transducer.
Discharge Pressure SP#2 Fail –	This message will appear when the discharge pressure exceeds the safety setting of the Hi Dsch Press Trip Setpoint No. 2 . In addition, this message will appear when the discharge pressure reading falls below 30” Hg, indicating a shorted transducer
Suction Temp Fail –	This message will appear when the suction temperature falls below the safety setting of the Low Suction Temperature Trip setpoint. In addition, this message will appear when the suction temperature rises above 400 degrees, indicating an open RTD.
Discharge Temp Fail –	This message will appear when the discharge temperature rises above the safety setting of the High Discharge Temperature Trip setpoint. In addition, this message will appear when the discharge temperature falls below -30 degrees, indicating a shorted RTD.
Oil Separator Start Temp Fail –	This message will appear when the Oil Separator Temp is below the Low Oil Separator Start Temp Trip setpoint. In addition this message will appear after the Oil Separator Temp Safety Changeover timer times out and the Oil Separator temperature fails to rise above the Low Oil Separator Start Temp Reset after the compressor is started.
Oil Separator Run Temp Fail –	This message will appear when the Oil Separator Temp is below the Low Oil Separator Run Temp Reset setpoint after the Oil Separator Temp Safety Changeover timer times out.
Percent Capacity Fail –	This message will appear if the percent capacity reading exceeds 300% or goes below –15%.

Safety Failure Message

Percent Volume Fail –	This message will appear if the percent volume reading exceeds 300% or goes below –15%.
Lo Control Temperature Fail –	This message will appear when the Process Control Temperature falls below the safety setting of the Lo Control Temperature Trip Setpoint. In addition, this message will appear when the Process Control Temperature rises above 300 degrees F, indicating an open RTD.
Lo Start Oil Pressure Fail –	This message will appear with the Prelub Oil Pressure (Manifold minus Discharge) has remained below the Prelub Oil Pressure Reset setpoint. The Prelub Oil Pressure must be above the Prelub Oil Pressure for a time period of the Minimum Compressor Prelub time. It will continue to try to do this for a time period of the Prelub Oil Pump Time Limit. When the Prelub Oil Pressure fails to achieve this, then the failure message will occur.
Lo Oil Pressure Fail –	This message will appear when the Running Oil Pressure (Manifold minus Suction) has remained below the low Oil Pressure Reset setpoint when the Oil Pressure Bypass at Compressor Start timer times out. This message will also appear when the Running Oil Pressure falls below the Low Oil Pressure trip setpoint after the Oil Pressure Bypass at Compressor Start timer times out.
Lo Oil Injection Temp Fail –	This message will appear when the Oil Injection temperature falls below the Low Oil Injection Temperature trip setpoint. This message will also appear when the Oil Injection temperature fails to rise above the Low Oil Injection Temperature reset setpoint after the Low Oil Injection Temp Bypass timer times out.
Hi Oil Injection Temp Fail –	This message will appear when the Oil Injection temperature rises above the High Oil Injection Temperature trip setpoint.
Manifold Pressure Fail –	This message will appear with the manifold pressure rises above 300 PSI or falls below 30” Hg.
Filter Inlet Pressure Fail –	This message will appear with the manifold pressure rises above 300 PSI or falls below 30” Hg.
Start Filter Diff Press Fail –	This message will appear if the Filter Differential pressure rises above the High Fltr Diff Press – Start setpoint before the Filter Differential Pressure Safety Changeover timer times out.

Safety Failure Message

- Run Filter Diff Press Fail – This message will appear if the Filter Differential pressure rises above the High Fltr Diff Press – Run setpoint after the Filter Differential Pressure Safety Changeover timer times out.
- Maximum Amperage Fail – This message will appear if the motor amperage rises above the Hi Motor Amps trip setpoint.
- Motor Starter Aux Contact Fail – This message will appear if the Motor Auxiliary contact fails to close before the Compressor Starter Auxiliary Contact Bypass timer times out. Refer to wiring diagram.
- Auxiliary Safety#1 Input Fail – This message will appear when power is removed from the input module that is designated as “Auxiliary #1 Safety” (please refer to your wiring diagram).
- Lo Oil Separator Level Fail – This message may appear when power is removed from the input module that is designated as “Lo Separator Oil Level Trip” (please refer to your wiring diagram). This safety has an associated delay. The associated delay timer is the Lo Oil Separator Level Bypass Timer. This safety will activate only after the oil level has been low after the timer times out.

Suppressor Kit Installation



Drawn By: Carie

Checked By: Sheri P

Approved

Date
1-26-05



T00451 1/1 R1


Kit 785 (Suppressor RF Kit) Installation Instructions

Kit Purpose:


This kit is used to help reduce interfering noise frequencies, that may cause unexplained interruption or interference with panel.

(Examples of causes of electrical noise: Are two way radios, AC voltage too close to DC leads, etc.)

Item	VPN
 Ferrite Bead Tubular	3149A
 Ferrite Clamp On Cylindrical	3149B



Place a large ferrite to the power line coming into panel as shown.




Note: Does Not Apply To Quick Connects. The kit provides extra ferrites.

Revisions: Add ferrite to all actuators. 1/27/05

Flash Card Installation Instructions

Note: Before Powering Down To Replace Flashcard, You Must Copy Down All Setpoints As These Will Need To Be Re-entered When New Flashcard Is Installed.



Hit The Emergency Stop Button
Located In Front Of The Panel




Verify Unit is Shut Down Completely



Verify Lockout Disconnect On Compressor Start.
This Ensures Compressor Does Not Start.

Proceed As Follows


Disconnect the Connector And
Ribbon As Shown




View Inside Of Door

Remove (4) Screws, One In
Each Corner Of Board



Flip Board Over To
View Flash Card



Flash Card Installation Instructions




Remove Flashcard And Replace




Reconnect Connectors and Ribbons

Flip Board Back Into Position
Secure Board To Mounts
With Previously Removed Screws




Note: You Must Re-enter Setpoints And Recalibrate Slide Valves.
See Section On Setpoint Values And the Section On Optical Actuators.

Back Light Installation Instructions




Back Light Installation Instructions

Remove Small Screw
And Slide Back Light
Out As Shown




Slide New Back Light In And
Secure With Previously Removed Screw




Back Light Installation Instructions


Place Board Back Into Position And Secure




Connect Ribbon And Plug Connector Back In




Place Board Back Onto Back Of Panel And Secure With Previously Removed Nuts




Transducer Wiring

	VILTER MANUFACTURING CORPORATION CUDAHY, WISCONSIN 53110-8904 TELEPHONE No. (414) 744-0111	DRAWN BY	REDRAWN BY	CHKD BY	APPR. BY	DATE	T00448 R0
		SLP		JKK	MTW	08/15/03	


VISSION/VANTAGE WIRING FOR AMETEK TRANSDUCER (2783A)




2895 MICROCONTROLLER WIRING FOR AMETEK TRANSDUCER (2783A)




VISSION/VANTAGE WIRING FOR SETRA TRANSDUCER




2895 MICROCONTROLLER WIRING FOR SETRA TRANSDUCER



VISSION/VANTAGE WIRING FOR DANFOSS TRANSDUCER (2783J & 3122B)



2895 MICROCONTROLLER WIRING FOR DANFOSS TRANSDUCER (2783J & 3122B)



REVISIONS: Initial Release MTW 8/18/03 ECN M030096.

System Setpoints Alarms and Trips Work Sheet

SAFETY SETPOINTS	SYSTEM VALUES ALARM TRIP RESET	VALUE LIMITS			DEFAULT VALUES		
		ALARM	TRIP	RESET	ALARM	TRIP	RESET
LO SUCTION TEMP		-99/300	-99/300	-99/300	-45	-50	-40
HI DISCHARGE TEMP		-30/260	-30/260	-30/260	205	210	200
LO OIL SEP START TEMP		50/200	50/200	50/200	75	70	80
LO OIL SEP RUN TEMP		50/200	50/200	50/200	105	100	110
LO OIL INJECT TEMP		50/160	50/160	50/160	95	90	100
HI OIL INJECT TEMP		-99/160	-99/160	-99/160	140	145	135
LO CONTROL TEMP (3) (2)		-99/210	-99/210	-99/210	-50	-55	-45
HI CONTROL TEMP (3) (2)		-99/210	---	---	100	---	---
LO SUCT PRESS SETPOINT #1		30"/300	30"/300	30"/300	3"	4"	3"
SETPOINT #2		30"/300	30"/300	30"/300	1"	2"	1"
HI DISCHARGE PRESS SETPOINT #1		30"/350	30"/350	30"/350	210	220	205
SETPOINT #2		30"/350	30"/350	30"/350	220	230	215
PRELUB OIL PRESSURE		---	4/300	4/300	---	4	5
LO OIL PRESSURE (2)		18/300	18/300	18/300	38	35	40
HI START FLTR DIFF PR		30"/50	30"/50	30"/50	50	50	25
HI OIL RUN FILTER DIFF PR(1)		30"/40	30"/40	30"/40	12	15	10
HI AMPS LIMIT (4)(5)		0/1000	0/1000	0/1000	15	15	---

NOTES:

- (1) If your unit is equipped with new style filters (Vilter Part #3109B or 3110B), the Alarm should be set at 37 psig, Trip at 40 psig and Reset at 35 psig.
- (2) For boosters, set Alarm at 28 psig, Trip at 25 psig, Reset at 30 psig.
- (3) Set Alarm at 60% and Trip at 70% of full load motor nameplate amps. Only if Process Temp Control
- (4) Set Alarm at 120% and Trip at 125% of full load motor nameplate amps.

System Control Limit Values Work Sheet

SYSTEM CONTROL LIMIT VALUES WORKSHEET

CONTROL LIMITS	SYSTEM VALUES		VALUE LIMITS		DEFAULT VALUES	
	CUT IN	CUT OUT	CUT IN	CUTOUT	CUT IN	CUT OUT
SUCTION PRESSURE ON/OFF (1)						
SETPOINT #1			30"/150	30"/150	10	6
SETPOINT #2			30"/150	30"/150	15	11
SUCT PR CAP INCREASE (1)						
SETPOINT #1			30"/150	30"/150	20	25
SETPOINT #2			30"/150	30"/150	20	25
SUCT PR CAP DECREASE (1)						
SETPOINT #1			30"/150	30"/150	18	23
SETPOINT #2			30"/150	30"/150	18	23
HIGH DSCH PRESS UNLD (1)						
SETPOINT #1			0/300	0/300	200	190
SETPOINT #2			0/300	0/300	210	200
LIQ INJECTION SOLENOID CONTROL			ON	OFF	ON	OFF
TEMP VIA:						
OIL INJECTION TEMPERATURE			<u>200°F</u>	<u>50°F</u>	<u>120°F</u>	<u>105°F</u>
OIL SEPARATOR TEMPERATURE			<u>200°F</u>	<u>50°F</u>	<u>120°F</u>	<u>105°F</u>
OILPMP RESTART (D/S)			1.0/8.0	1.0/8.0	2.8	3.0
OIL SEPARATOR HEATER			80/130	80/130	95	105
CAP CTRL °F ON/OFF (2)						
SETPOINT #1			-99/200	-99/200	20	10
SETPOINT #2			-99/200	-99/200	25	15
CAP CTRL °F INCR (2)						
SETPOINT #1			-99/300	-99/300	28	27
SETPOINT #2			-99/300	-99/300	33	32
CAP CTRL °F DECR (2)						
SETPOINT #1			-99/200	-99/200	24	25
SETPOINT #2			-99/200	-99/200	29	30
LAG, CAPACITY STEP (3)			0/100	---	10	---
VOL SLIDE ADJ FACTOR			-100/100	---	0%	---
MINIMUM RUN CAPACITY			10% / 90%	---	30	---
LEAD, MAXIMUM CAP FLAG (3)			50/100	50/100	95	90
ECONOMIZER SOLENOID			0% / 100%	0% / 100%	80%	75%*
VOL ADJ CAP RANGE			0/100	---	100%	100%
LOW SUCTION PRESS LOAD LIMIT						
SETPOINT #1						
SETPOINT #2						
LOW SUCTION PRESSURE LOAD LIMIT			ON	OFF	ON	OFF
SETPOINT #1					30	35
SETPOINT #2					40	45
MOTOR AMPS LOAD LIMIT (4)						
SETPOINT #1			0/999	0/999	5	10
SETPOINT #2			0/999	0/999	5	10
CURRENT TRANSFORMER (1)		C/T RATIO	C/T RATIO 100-1000/AMPS		C/T RATIO 100/5 AMPS	

NOTES:

- (1) Must be field set.
- (2) Set only if temperature is used for capacity control.
- (3) Set only if Lead/Lag option is selected.
- (4) Set FLA at nameplate amps, MAX at nameplate + service factor.

System Timer Values

The values or options in the screen displays shown must be entered before start-up.

SYSTEM CONTROL LIMIT VALUES WORKSHEET

TIMER VALUES	SYSTEM VALUES	VALUE LIMITS	DEFAULT VALUES
AT START CAPACITY DECREASE		0/999 SEC	15 SEC
CAPACITY INCREASE MOTOR ON		0/255 SEC	2 SEC
CAPACITY DECREASE MOTOR ON		0/255 SEC	2 SEC
CMP STARTER AUX CONTACT BYPASS		0/255 SEC	10 SEC
CAP INCREASE MOTOR OFF		0/255 SEC	20 SEC
CAP DECREASE MOTOR OFF		0/255 SEC	10 SEC
VOL SLIDE ADJ TIMER		0/255 SEC	20 SEC
MINIMUM CAP PRELUB TIME		0/255 SEC	5 SEC
RUN CYCLE OIL PRESS BYPASS		0/90 SEC	60 SEC
PRELUB PUMP TIME LIMIT		0/255 SEC	255 SEC
FLTR DIFF PR SAFETY CHANGEOVER		0/999 SEC	60 SEC
LO OIL SEP LEVEL BYPASS TIMER		0/120 SEC	60 SEC
AUTO RESTART AFTER POWER FAIL		1/240 MIN	5 MIN
OIL SEP TEMP SAFETY CHANGEOVER		0/15 MIN	5 MIN
LO OIL INJ TEMP SFTY CHANGEOVER		0/15 MIN	6 MIN
ANTIRECYCLE STRT TIMER (MIN) (1)		0/30 MIN	20 MIN
FORCE START LAG COMP (MIN) (2)		0/60 MIN	30 MIN
HOT STRTS/HR COUNTER (COUNTS) (1)		1/10 COUNTS	3 COUNTS

NOTES:

- (1) Must be field set.
- (2) Set only if Lead/Lag option is selected.

In consideration of the receipt of this document, the recipient agrees not to reproduce, copy, use or transmit this document and/or the information therein contained, in whole or in part, or to suffer such action by another for any purpose, except with the written permission of Viter Manufacturing Corporation and further agrees to surrender same to Viter Manufacturing Corporation upon demand.

ITEM	DESCRIPTION	PART NO.
1	ANALOG BOARD	3010A
2	1/2 MODULE & RELAY BOARD	3010B
3	TOUCHSCREEN INTERFACE BOARD	3010C
4	VISION CABINET	3010D
5	FUSE KIT	3010F
6	VISION EMERGENCY STOP	3010H
7	VISION RESISTIVE TOUCHSCREEN	3010J
8	VISION POWER SUPPLY	3010K
9	VISION GRAPHIC OVERLAY	3010L
10	VISION SBC SUB-ASSEMBLY	3010M
11	DRAM MODULE, 16MB	3010P
12	FLASHCARD, 64M	3010FC1
13	AC INPUT 90-140 VAC	28995A
14	AC OUTPUT 12-140 VAC	28995B
15	FUSE 4.0 A	28995P
16	FUSE .5 A	3010V
17	FUSE 5 A 250V, 2AB SLD-BLD	3010Z
18	RELAY, SPDT	3010A1
19	RELAY, SPDT	3010A1
20	RELAY, 4PDT	3010B1
21	FUSE 7 A 250V, 2AB SLD-BLD	

- NOTES:
- 1) ALL CUTOUPS MUST BE DEBURRED
 - 2) REFERENCE DRAWINGS
 - 3) ALL CUTOUPS AND MIG HOLES BY ENCLOSURE MANUFACTURER.

CONTROL PANEL: SINGLE SKIN# 1109 42144

VISION MANUFACTURING CORPORATION
1000 W. 100th St., Suite 100
Eden Prairie, MN 55324
TEL: 952.941.1000 FAX: 952.941.1001


DATE: 11/11/02

DESIGNED BY: MCB
CHECKED BY: MCB
DRAWN BY: MCB


VISION MANUFACTURING CORPORATION, PANEL LAYOUT
VISION MANUFACTURING CORPORATION, PANEL LAYOUT
VISION MANUFACTURING CORPORATION, PANEL LAYOUT

STD FILE 42144 1 R1


DOOR LAYOUT



SUBPANEL LAYOUT




DETAIL-D
PANEL BOTTOM LAYOUT




DETAIL-B

TRANSUCES JUMPER CONFIGURATION
STANDARD JUMPER SETTINGS



DETAIL-A

STD. JUMPER CONFIGURATION
STANDARD JUMPER SETTINGS



SEE DETAIL-D
BRING IN AC WIRING HERE

Spare Parts

PART DESCRIPTION	VILTER PART NUMBER	QTY.
Analog Board (VISSION PANEL)	3011A	1
Analog & Relay Board (VANTAGE PANEL)	3011C1	1
Control Relay, 4PDT	3011B1	1
Control Relay, DPDT	3011A1	1
Control Relay, SPDT	3011Z	1
Input Module	2895M (120v)	1
Output Module	2895N (120v)	1
Output Module Fuse	2895P	1
Panel Fuse, ½ Amp	3011V	1
Panel Fuse, 10 Amp	3011W	1
Panel Fuse, 4 Amp	2895P	1
Power Supply	3011K	1
Relay Board (VISSION)	3011B	1
Pressure Transducer	2783J	1
Resistance Temperature Detector	2611G	1
Fuse Kit (VISSION PANEL)	3011F	1
Fuse Kit (VANTAGE PANEL)	3011F1	1
VISSION SBC Sub-Assembly	3011ML	1
Modbus Cable	3011X	1
VISSION Cable Kit	3011Y	1
RTD/Transducer Cable	3122B	1
Cable Kit (VANTAGE PANEL)	3011Y1	1
Modbus Cable Kit (VANTAGE PANEL)	3011X1	1
CORD SET		
RK4T-4/ 5618Turk	3122B	1
64m Flashcard	3011FC-1	1
Lighted Emergancy Switch	3011H	1
Snubbers	3030C	1
Supressor Kit	KT785	1

*Supplied with 120VAC. input& output modules.

Modifications for Analog Board (Vission/Vantage after July 2003)

Using Danfoss Transducers with 2783J qualified boards

The analog boards used in the Vission and Vantage panels after July 2003 have been modified to accommodate the use of Danfoss transducers (VPN 2783J). These analog boards are denoted as “2783J qualified” boards. The use of 2783J qualified boards with Danfoss transducers require that scaling factors for the Danfoss pressure transducers be checked and modified if necessary.

The scale factors for all transducers are located at a specific Index location in Vission/Vantage database. Refer to Figure 1. This table shows the proper scale factors for each type of transducer as well as the Index location of the scaling factor for each transducer.

Vission and Vantage (VSS and SOI units)			Vission (VRS units)		
Transducer	Index	Value*	Transducer	Index	Value*
Suction	N658	3950	Suction	N658	3950
Discharge	N659	3950	Discharge	N659	3950
Man/Filter Out	N660	3950	Manifold	N660	3950
Filter In	N661	3950	Filter Inlet	N661	3950
			Filter Outlet (Retrofit)	N664	3950
Vission and Vantage (Cool Compression units)			Vantage (Recip)		
Transducer	Index	Value*	Transducer	Index	Value*
Suction	N658	3950	Suction	N658	3950
Discharge	N659	3950	Discharge#1	N659	3950
Man/Filter Out	N660	3950	Filter Out	N660	3950
			Filter Inlet	N661	3950
			Discharge#2	N662	3950
			Oil Manifold	N663	3950
			Crankcase	N664	3950

Figure 1. Transducer Index Table and Scale Factors

Value* : The value 3950 shown is the Scale Factor for transducers manufactured by Ametek and Setra. This does NOT include Danfoss transducers. **If Danfoss transducers are being used with 2783J qualified boards, the “Value” at the Indexes shown above needs to be modified to 4297.** The procedure on the next page describes how to modify the scaling factor.

Modifications for Analog Board (Vission/Vantage after July 2003)

The procedure to Change Scale Factors on 2783J Qualified Board

1. From the Main Screen, press the Menu button.
2. From the Menu Screen, press the Vilter ONLY screen.
3. Logon
4. From the Vilter ONLY screen, press the Raw Data Screen button.
You will now see a screen labeled "Data Test", containing 4 columns, 2 labeled "Index" and 2 labeled "Value".
5. Press the "Set" button and then press one of the blank boxes under either one of the Index columns.
6. A keypad will be displayed. Now type in "N658" (without the quote marks). Press the OK button. (Per the table, this is the Index for the Suction Pressure transducer.)
7. You are now returned to the "Data Test" screen. You will see "N658" in the box that you touched, and you will see the value 3950 in the corresponding "Value" box. This is the scale factor that will be changed.
8. Now press the "Set" button again, and press the "Value" box that contains the value 3950. A numeric keypad will now be visible.
9. Press the Clear button. Now press the buttons 4297, followed by pressing the "Enter" button. You will now be returned to the "Data Test" screen, and the Value field that previously contained 3950 now contains the Value 4297. Per the table below, you have now corrected the scaling factor for the Suction Pressure transducer.
10. Continue this process, entering in "Index" values and changing the scaling factors for all transducers. (Reference Figure 1 below.)
11. When completed, press the OK button and return back to the main screen.
12. Now go to the LOGON screen and perform a "BACKUP SETTINGS". After a minute or so, the new scale factors will be "active".
13. You may now need to recalibrate your transducers again, as the new scale factors will affect the current readings of the transducers. If you have gauges on your system, you can do this using your gauge readings. When you have completed re-calibration of all your transducers, do another "BACKUP SETTINGS".


	2895A	3011A Vission	3011C1 Vantage	3011A Vission (2783J qualified)	3011C1 Vantage (2783J qualified)
Ametek VPN 2783G	Yes	Yes	Yes	Yes	Yes
Danfoss VPN 2783J	No*	No	No	Yes-Rescale	Yes-Rescale
Setra VPN 2783K	Yes	Yes	Yes	Yes	Yes

Table II The acceptable mix of analog boards and transducers.

No* = this combination of board and transducer will result in a very slight scaling error (2 percent error over entire 0-300 PSIG range of transducer). Vilter does not recommend using the Danfoss transducer with a 2895A board.

Warning -If a Danfoss Transducer is used with a non-qualified 2783J Analog Board, the transducer will not properly read pressures over 165 PSIG.

Danfoss Liquid Injection Valves



Setup Screen


1. Press “Setup”
2. Select “Enable” for Liquid Pos. Valve
3. Press “OK”
4. Press “Vilter Only”, you will be prompted to Log In
5. Press “Liquid Inj. Temp Control” then you will see the screen as in the attached picture “Liquid Inj. Control”, the values you see there are default and can be changed according to your application.



Vilter Only Screen

NOTE:

Consult the VSS / VSM / VSR Unit Manual for proper Danfoss ICM valve setup procedure.



Liquid Inj. Temp Control Screen

Who to Contact

If service is required, first contact your equipment distributor or contact
A Vilter Technical Service Representative at:

Vilter Manufacturing LLC
5555 South Packard Ave.
PO Box 8904
Cudahy, WI 53110-8904
Tel: 414-744-0111
Fax: 414-744-1769
e-mail: info.vilter@emerson.com

www.vilter.com

Note: It will be necessary to have your Vilter order number available
when contacting Vilter Manufacturing Corporation for service support.

Disclaimer: Specifications are subject to change without notification.

EmersonClimate.com

Vilter Manufacturing LLC
P.O. Box 8904
Cudahy, WI 53110-8904
P 414 744 0111
F 414 744 1769

www.vilter.com

VILTER[®]
Since 1867

Vilter Manufacturing LLC are trademarks of Emerson Electric Co. or one of its affiliated companies.
©2011 Emerson Climate Technologies, Inc. All rights reserved. Printed in the USA.

353915A Rev 06


EMERSON[™]
Climate Technologies